

kogan

ΣΟΨ VÔÍ ÚÔÆÈÆ

USER MANUAL



USER'S MANUAL



1. FUNCTIONS OF THE WATCH

In normal mode the display will show the month, day, hour, minutes, seconds and day of week. The alarm function keeps the alarm ringing for 10 seconds.

2. ALARM SETTING

In normal display mode, B is the mode button. Press the B button to enter alarm setting mode. Pressing the A button activates and deactivates the alarm and time signal.

Press C, time starts to flash, now press A to set the time and if there's an icon will alert the PM in the afternoon. Pressing C will flash the minutes, then press A to set them. Press B to exit from setting the alarm.

3. FUNCTION STOPWATCH

In normal display mode press B twice, then you will be in stopwatch mode.

Pressing A will start the stopwatch, press A again to stop the clock, with the C button pausing the timing. The timer will be suspended, so press the C and the stopwatch will continue to function.

Press A then C to return the stopwatch back to 00.00.

Press B to exit.

4. SETTING THE TIME

In normal display mode pressing the A button will change between 12/24 hour modes.

To set time press the B button three times, the seconds will flash, press the A button to bring the seconds to zero.

Pressing C will select the hour, press A to set the hour. Pressing C to select minutes, then press A to set the minutes. Press C to select month mode, then press A to change the month. Pressing C again will go into day mode. Select the date in the month using A. Finally, press C to go into weekday, then press A to cycle through the weekdays. Press B to return to normal display.

5. LIGHT

In dark areas, you can highlight the time with an LED light by pressing C.

6. REPLACING THE BATTERY

When the battery runs out you must replace it as soon as possible to prevent any malfunction of the watch.

For replacement, we recommend that you contact the Kogan Customer Support team.

Batteries must be properly disposed of and to this end, the shops that sell batteries are also provided with special containers for disposal to protect the environment.

WARNINGS

Do not remove the battery from the watch. If it should be necessary to remove it, keep the battery away from children.

In the event that a battery is swallowed, seek urgent medical help immediately!