SereneLife

USER MANUAL



SLFTSP18 Pedicure Spa Foot Massager

Vibrating Heated Foot and Ankle Detox Spa with Red LED Light and Detachable Pedicure Accessories

SLFTSP18 FOOT SPA INSTRUCTION MANUAL

- DESCRIPTION
 - 1. Housing
 - 2. Operation mode board
 - 3.20 air jets
 - 4. Acupuncture Ball
 - 5. Brush massager
 - 6. Pumice stone
 - 7. Anti-splash lid
 - 8. Foot massage rollers
 - 9. Lifting-up ring
- 10. Drain spout



IMPORTANT SAFEGUARDS

- Please read this instruction manual carefully before use and keep in a safe place for future reference.
- Before using this appliance for the first time, always ensure that the voltage on the rating label corresponds to the mains voltage in your home.
- For home use only. Do not use for industrial purposes. Do not use the appliance for any other purposes than described in this instruction manual.
- Do not use outdoors.
- Always unplug the appliance from the power supply before cleaning and when not in use.
- To prevent risk of electric shock and fire, do not immerse the appliance in water or any other liquids. If it has happened DO NOT TOUCH the appliance, unplug it immediately and get it checked in an authorized service center.

2

• Do not take this product to a bathroom or use in humid conditions.

- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliances by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Do not leave the appliance switched ON when not in use.
- Do not use other attachments than those supplied.
- Do not operate after malfunction or cord damage.
- Do not attempt to repair, adjust or replace parts in the appliance. In case of any malfunction, please contact the brand authorized service center.
- Keep the cord away from sharp edges and hot surfaces.
- Do not place or store the appliance where it can fall or be pulled into a tub or sink.
- Do not pull, twist, or wrap the power cord around the appliance.
- The massager is designed for intermittent use: it can be applied without interruption not longer than 15 minutes, then the motor must be allowed to cool.
- Do not use the massager if you are pregnant, or suffer from thrombosis, open wounds, torn skin or varicose veins. Consult your doctor first.
- Do not attempt to plug in or unplug the unit while feet are in water.
- Do not stand up or place any objects in the unit, use it only when you are sitting.
- If you feel discomfort or any pain or irritation while using the device, immediately stop using it; never use for swollen or inflamed feet, or if feet have any skin eruptions. First, consult your physician.
- If a unit is leaking, the device cannot be used. Contact Customer Support.
- The manufacturer reserves the right to introduce minor changes into the product design without prior notice, unless such changes influence significantly the product safety, performance, and functions.

• FEATURES

- Ergonomic design with massage pegs and cushions for massaging biologically active areas.
- Regular feet massage improves the blood circulation substantially, especially in the feet.
- The built-in heating element heats the water and maintains certain temperature during the whole massage procedure.
- 20 air holes in the massage surface provide a relaxing bubble bath.
- Bubble function to clean your foot pores.
- Stronger Vibration function inbuilt provide relaxing massage .

• LED OPERATION PANEL INSTRUCTION (2)



1. POWER BUTTON:

(When you plug the foot-massager in the socket, the power pilot lamp is turned ON, and LED display "OFF") Push the power button one time, the built-in heating element will start to heat the cool water and LED displays the water temperature-change, (The LED display 108°F three times, then display the actual water temperature (we recommend 108°F as the safe spa temperature.)

NEVER PRESS POWER BUTTON IF THERE'S NOT ENOUGH WATER INSIDE THE TUB. DO NOT USE WITHOUT WATER.

Push Power button once again to stop the foot spa . Always unplug the massager after foot spa.

2. TEMP. (TEMPERATURE) BUTTONS:

When you Push the "**Power**" button one time, the built-in PTC heating element start to heat the cool water and LED display the water temperature-change, If the heating lamp is bright, it means that the PTC is working. Pls keep there is enough water in the tub.

Choose to push the 2 bottons (\blacktriangle \And \blacktriangledown) to control temperature of water,

LED showing you the temperature in Fahrenheit, 95°F-118°F.

(The foot spa massager is with some automatic function, Just check the details in point 6)

3. BUBBLE & RED-LIGHT BUTTON:

Push this button to switch bubble and redlight function.

3 Modes: Bubble & redlight - Bubble - Stop.

4. TIME BUTTON:

Push it continuously to set time (10 to 60 mins). Time lamp will be turned ON & OFF accordingly.

5. VIBRATION BUTTON:

Turn ON & OFF Vibration function.

6. THIS FOOT SPA MASSAGER IS DESIGNED WITH AUTOSTART FUNCTION:

Push power button to start heating the water. When the water temperatures up to 95°F, it will automatically start the bubble and Red light; When waters heated to 108°F, it will automatically start the Vibration massage.

Before turning ON the foot spa massager, please make sure you had poured enough water into the tub.

SPA MASSAGE

- Place the massager on steady surface, the special rubber legs will prevent the device from sliding.
- Ensure that the unit is unplugged before filling with water.
- Prior to turning the device ON, pour water in the tub. Fill the foot spa massager with cool or warm water. Do not pour the water over the maximum level mark indicated in the inner wall of the tub.
- Select one of three massage attachments and place it in the center of the massager.
- Push the power button ON, ensure no leaking in the tub.
- Feel the water temperature firstly by hand before placing in your feet.
- Sit down on chair or other safe place, and place your feet in the spa massager.
- Push the function buttons of your choice to start the massage function.
- Choose the vibration button to stimulate feet muscles.

The acupressure rollers are designed according to the foot reflexology points, and it can eliminate your fatigue.

SAFE FOOT-SPA: FIRSTLY POUR ENOUGH WATER (HIGHER THAN THE LOWEST WATER LINE, LOWER THAN THE HIGHEST WATER LINE), SECONDLY PLUG THE DEVICE IN THE SOCKET, PUSH THE POWER BUTTON. THEN MAKE SURE THERE IS NO LEAKAGE OF WATER FROM THE TUB. FINALLY PUT YOUR FEET INSIDE THE TUB TO ENJOY FOOT SPA MASSAGE.

WARM WATER SPA, VIBRATION & BUBBLE MASSAGE

Bubble function will increase Oxygen to clean your feet. Vibration function promotes blood circulation.

If you are pouring cold water, you should wait until the water warms up to a suitable temperature. The heating element will keep the water warm during the whole massage process. Just relax yourself to enjoy the spa massage process.

- CAUTION
- BEFORE INSERTING YOUR FEET IN THE WATER TUB, PLUG IN THE POWER SUPPLY.
- BEFORE PUSHING THE POWER BUTTON, MAKE SURE THERE IS ENOUGH WATER INSIDE THE TUB, OR ELSE THE DEVICE MAY GET DAMAGED. NO WATER NO USE!!!
- FOR YOUR OWN SAFETY, DO NOT ADD WATER HOTTER THAN 108°F INSIDE THE TUB.
- WE SUGGEST 108°F WARM WATER SPA MASSAGE. DON'T BEAR TOO HIGH TEMPERATURE ON YOUR FEET.
- DO NOT STAND INSIDE THE FOOT SPA TUB.

AFTER USE

• FIRST, push the power button one time to stop the massager working, then unplug the unit. Pull the tub by lifting-up ring (9), Tilt the unit allowing water to spill out along the drain spout (10).

Never pour water over the LED OPERATION PANEL (2)

CLEAN AND CARE

- Unplug the appliance off and ensure that the massager has completely cooled.
- Do not use hard abrasives or chemistry cleaners.
- Attachments may be cleaned in soapy water
- After using, simply rinse out with water. Never immerse the entire unit into water. You can wipe off all surfaces with a cloth damped with water and a mild detergent, then rinse and dry.

• STORAGE

- Be sure that the appliance is unplugged and cooled down.
- Complete instructions of section CLEAN AND CARE
- Keep the appliance in a cool, dry place.

SLFTSP18

Pedicure Spa Foot Massager

Vibrating Heated Foot and Ankle Detox Spa with Red LED Light and DetachablePedicure Accessories

Features:

- Portable Foot Massager and Spa with Red LED Lamp
- Foot Bath with Red LED Light Improves Blood Circulation
- Massage Rollers Targets Acupuncture Points
- Strong Vibration Massage Stimulates Feet Muscles
- Bubble Spa Aerates Warm Water to Release Oxygen
- Detox and Soften Hard and Calloused Feet and Ankles
- DetachablePedi Accessories for Ultimate Foot Spa Experience
- Heated Water Therapy Relaxes Tired and Aching Feet
- Variable Time Intervals and Different Massage Levels
- PTC Heating Semiconductor Prevents Overheating
- Easy to Use: Simple Smart Buttons for Function Choices
- WideLCD Display to OSD and Modes
- Top Cover to Protect from Dust and Splash
- Medical Grade Construction Material
- Portable: Ergonomic Lift-Up Ring Design
- Pamper your Feet with a Luxurious Foot Spa Bath!

What's in the Box:

- Foot Spa Massage Tub
- Acupuncture Ball
- Brush
- Pumice Stone

Technical Specifications:

- Construction Material: PP
- Maximum Support Feet Size: (US Size)Up to 32cm
- Tank Capacity: 289 Oz

SereneLife



VISIT US ONLINE: Have a question? Need service or repair? Want to leave a comment? PyleUSA.com/ContactUs

