
SLGRF20SL


Golf Laser Rangefinder
Digital Golf Distance Meter
USER MANUAL





- 1: Laser Emission/Objective Lens
- 2: Laser Receiving Lens
- 3: Unit Switching Button
- 4: Power/Start Button
- 5: Observation Eyepiece
- 6: Rotation-type Focusing
- 7: Battery Cover

LCD Display Icons



- 1: "SCAN"--- Scanning Mode Sign;
- 2: ----- Low Battery Indicator
- 3: 🛨 ----- Target
- 4:

 ✓ ----- Laser Indicator
- 5:888 ----- Distance Data Shows
- 6: "M/Y"----- Unit "meter" or "yard"

SereneLife Operating Instructions


A. Start:

Press **START/POWER** button of for about 1 second and the laser Rangefinder monocular will start. The laser indicator swill blink when laser is transmitting. If the reflection of the target is too weak, the LCD will display "______".

B. Eyepiece:

Eyepiece is adjustable, as shown in picture below. It's designed for better vision and to resist external lights.

- **1.** Rotate the focus ring counterclock wise to extend the eyepiece.
- **2.** Rotate the focus ring clockwise to shorten the eyepiece.



C. Pin Seeking (Golf Flag Lock):

Aim at the golf flag or pin, keep pressing the power button and move it a little left and right until the distance of the flag or sticks is locked and displayed on the LCD. Move a little to left and right in order for the instrument to identify the distance from closest object (the flag or pin).

D. Meter/Yard Change:

Keep pressing the "**mode**" button for almost 2 seconds, the unit switch between M (meter) and Y (yard)

E. Low Battery Icon:

When icon shows, means the battery is low and should be replaced immediately to avoid inaccuracy.

F. Automatic Power OFF

Laser Rangefinder will automatically power **OFF** in 20 second without operation

Notice

- 1. In order to protect the coating of the lens, do not use your fingers to touch the surface.
- 2. Laser Rangefinder has been precisely assembled by instruments, please don't disassemble by yourself. Please send the device back to the dealer for repairing when needed.
- 3. When the lens needs cleaning, please wipe gently with cleaning cloth, do not use other objects to wipe it.
- 4. Avoid heavy collision when carrying the object.
- S. Keep the product away from moisture during storage. Please keep it in a dry, cool, and well ventilated place, and avoid direct sunlight, dust and high temperatures.
- 6. Rain and fog weather will affect the laser path, which may cause measurement errors.

Warning

- Do not stare into the laser beam.
- Eyes can be permanently damaged by looking into the sun with this device.
- Do not aim the rangefinder directly at the sun as permanent inside component damage will occur.
- Keep the eyepiece away from direct sunlight.
- Device is to be stored safely in a temperature environment set to -4°F - 140°F

Features:

- Precise, Accurate & Reliable
- Smart Digital Interface Display Readout
- Helps Improve Your Golf Game & Depth Perception
- (2) Selectable Modes: Pin-Seeking & Distance Measuring
- Simple Button Control Operation
- Compact Handheld Design
- Adjustable Manual Lens Focus
- **Battery Saving Function:** Automatic Power Off
- Great for Use at the Driving Range
- Used by Casual & Professional Golfers
- Includes Convenient Travel Case

Technical Specs:

- Measuring Range: 5.5 546.2 Yards
- Accuracy: +/- 1 Yard
- Selectable Measuring Units: Yards/Meters
- Optical Objective Lens: 24mm
- Field of View: 7°, Magnification: 6X
- · Construction Material: Engineered ABS
- Battery Operated: Requires (1) x 'CR2' (Lithium, 3V), Included
- Dimensions (L x W x H): 4.0" x 1.6" x 2.9"
- Sold as: 1