

INSIGNIA™

## QUICK SETUP GUIDE

# LED Tape Light


NS-LED4W18

## PACKAGE CONTENTS

- LED tape light
- Double-sided tape
- *Quick Setup Guide*

## FEATURES


- Premium white LEDs produce bright, natural light
- Multi-step dimmer adjusts to the brightness level you want
- Self-adhesive backing attaches to TVs, cabinets, or other spaces for quick, custom lighting
- Reduces eye strain from TVs and monitors while enhancing image contrast
- Lights powered through USB (on your TV or computer) or with a USB power adapter (not included)



## USING YOUR TAPE LIGHT

### Shortening your tape light

- Use a pair of scissors to cut on a cut line. Cut lines are about 1.3 in. (3.3 cm) apart.  
**Warning:** Do not cut the silver solder markings. Only cut in the center of the copper-colored pads, as shown.



### Attaching your lights




- 1 Peel the adhesive backing off the lights, then adhere the lights where you want them.
- 2 Attach the double-sided tape to the back of the light control, then adhere it where you want it. (optional)

### Connecting to power

- Place the tape light where you want it, then connect the USB connector to your TV, computer, or other USB power source.

## Adjusting the lights

**Note:** Tape light will retain the last brightness setting used when turned off, then back on.


- Press  (POWER) to turn the tape light on and off.
- Press  (BRIGHT) or  (DIM) to increase or decrease the brightness. There are eight light levels.

## SPECIFICATIONS

- Input: 5V DC, 1A  
Minimum specifications for USB power supply (not included): 5V DC, 0.5A (1.0A or greater recommended)
- Length: 4 ft. (1.2 m)

## TROUBLESHOOTING

### LEDs will not turn on.

- Press the power button to make sure your light is turned on, then press  (BRIGHT) to increase the brightness.
- Make sure that your lights are connected to a working USB port or power outlet. If connected to a computer, turn on your computer.

### LEDs flicker or turn on and off.

- Make sure that your lights are plugged into a working power outlet or USB port. Try plugging into a different power source.
- Make sure that the cable is not damaged.

## SAFETY INFORMATION

- To avoid damage to the light strip, do not twist or bend the light strip 90° sharply.
- Do not cut the silver solder markings. Only cut in the center of the copper-colored pads.
- Do not plug in your lights when they are coiled. This can generate excess heat which can damage the product or connected device.

## ONE-YEAR LIMITED WARRANTY

Visit [www.insigniaproducts.com](http://www.insigniaproducts.com) for details.

## CONTACT INSIGNIA:

For customer service, call 1-877-467-4289 (U.S. and Canada) or 01-800-926-3000 (Mexico)

[www.insigniaproducts.com](http://www.insigniaproducts.com)

INSIGNIA is a trademark of Best Buy and its affiliated companies  
Distributed by Best Buy Purchasing, LLC  
7601 Penn Ave South, Richfield, MN 55423 U.S.A.  
©2017 Best Buy. All rights reserved.

**Made in China**