KEYPAD FEATURES

QUICK SETUP GUIDE

Wired Numeric Keypad


NS-PNKNUM19 / NS-PNKNUM19-C

PACKAGE CONTENTS

- Numeric keypad
- · Quick Setup Guide


SYSTEM REQUIREMENTS

- Windows® 10, Windows® 8.1, Windows® 8, Windows® 7, Mac OS 10.4 or higher
- One available USB port



SETTING UP YOUR KEYPAD

 Plug the USB connector into a USB port on your computer. Your computer automatically finds and installs the appropriate driver.
When the installation completes, you can use your keypad.



Notes:

- When you install your keypad on a Mac, you must select the ANSI format when prompted by the operating system. The keypad will not work if you select any other format.
- Number lock is not supported on Macs. When the keypad is installed on a Mac, pressing the number keys always inputs numbers and not the navigation functions.

CLEANING YOUR KEYPAD

Wipe the keypad with a damp, lint-free cloth.

TROUBLESHOOTING

My keypad is not working.

- Make sure that your computer meets the system requirements.
- Make sure that the USB connector is securely attached to a USB port on your computer.
- Try connecting your keypad to a different USB port on your computer.
- Make sure that the number lock is on (the Num Lock Indicator should be lit).

My keypad doesn't work after the driver is installed or removed.

Reboot your computer.

SPECIFICATIONS

Dimensions (L×W×H):1.090 × 5.161 × 3.507 in. (2.77 × 13.11× 8.91 cm) Weight*: 3.844 oz (109 g)

Cable length*: 47.244 in. (1.2 M)

*Values for weight and cable length are approximate.

LEGAL NOTICES

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- · Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

ONE-YEAR LIMITED WARRANTY

Visit www.insigniaproducts.com for details.

CONTACT INSIGNIA

For customer service, call 1-877-467-4289 (U.S. and Canada) or 1-800-926-3000 (Mexico) www.insigniaproducts.com

INSIGNIA is a trademark of Best Buy and its affiliated companies. Distributed by Best Buy Purchasing, LLC 7601 Penn Ave South, Richfield, MN 55423 U.S.A. ©2018 Best Buy. All rights reserved. Made in China