



WHAT TO EXPECT

As your robot learns your home, you may need to make some small adjustments to optimize performance.




SCHEDULING

For a constant state of clean™, set up a cleaning schedule in the app.



AVOID MOVING THE ROBOT OR DOCK


While your robot is cleaning, do not pick it up and move it, or move the charging dock—this could impact the robot's ability to map your home.



EMPTYING THE DUST BIN


During the first few weeks of use, the dust bin will need to be emptied frequently. Empty debris and dust into trash.

Remove any debris buildup between the filter and the plastic shield.



LIGHTING CONDITIONS

For best results, run your robot in well-lit conditions. If you run your robot at night, keep the lights on in the areas to be cleaned.



DOORWAYS AND THRESHOLDS

Your robot can easily climb over most thresholds, but if one is higher than 7/8ths of an inch, block it off with a BotBoundary® strip.

Please be sure to read the enclosed Shark® Owner's Guide prior to using your robot.

Shark IQ ROBOT®

QUICK START GUIDE

To stay current on our latest updates and features, **DOWNLOAD THE SHARKCLEAN™ APP.**

Search "SharkClean" in the app store.



Scan QR code with your phone's camera to quickly find and download the app


© 2020 SharkNinja Operating LLC. BOTBOUNDARY, SHARK, and SHARK IQ ROBOT are registered trademarks of SharkNinja Operating LLC. CONSTANT STATE OF CLEAN and SHARKCLEAN are trademarks of SharkNinja Operating LLC. APPLE, the Apple logo, and iPhone are trademarks of Apple Inc., registered in the U.S. and other countries. APP STORE is a service mark of Apple Inc., registered in the U.S. and other countries. GOOGLE, GOOGLE ASSISTANT, GOOGLE PLAY, the Google Play logo, and Android are trademarks of GOOGLE LLC.



@sharkcleaning


SETUP

STEP 1 PREP THE ROBOT




- Remove protective film from robot and dock.
- **Attach side brushes located in the red packaging.**
- **The power button on the side of the robot must be in the (I) ON position.**

STEP 3 CHARGE THE ROBOT



Place robot on dock to charge for **6 hours**. **Power button must be in the (I) ON position** and the robot must be aligned correctly, with its **FRONT** side against the dock. When charging begins, the robot will BEEP and the DOCK light will turn **BLUE**.

STEP 2 SET UP THE DOCK



Find a **permanent** location for the dock in a central area with a strong Wi-Fi signal. **Remove any objects** that are closer than 3 ft. from either side of the dock, or closer than 5 ft. from the front. Place the dock with its back against the wall, and connect the charging cord to the back. The **Indicator Light** will illuminate green when the dock has power.


STEP 4 DOWNLOAD THE SHARKCLEAN™ APP



Search "SharkClean" in the app store or scan the QR code and download.
NOTE: For more information on connecting your robot, see next page.


OPTIMIZING YOUR HOME FOR CLEANING

STEP 5 PREP YOUR HOME



Clear cords and remove small objects like toys, clothing, or drapes from floors. Open interior doors in rooms you want your robot to clean.

STEP 6 SET UP FOR SUCCESS



Use the BotBoundary® strip included in the box to keep your robot out of the areas you would like it to avoid:

- Near power cords or phone chargers.
- In front of thresholds higher than 7/8ths of an inch.


CONNECTING THE SHARKCLEAN™ APP AND ROBOT

Search SharkClean in the app store and download to get started.

Apple iOS Only

STEP 1 Create An Account


- Open the **SharkClean** app and set up your account.



STEP 4 Connect To Home Wi-Fi


- Select your home Wi-Fi network and enter your password.

NOTE: Most networks are **2.4GHZ**. The app will not work on a 5GHz network.



STEP 2 Activate Robot Wi-Fi

- Hold down **Dock** and **Clean** buttons **simultaneously** until the **Wi-Fi light** (📶) on the robot blinks.




STEP 5 Success!

- When pairing is complete, the **Success** screen will appear.



STEP 3 Select Robot

- Exit the app and open Wi-Fi settings.
- Select your robot (Ex. Shark_RVXXX) from the menu.
- Exit settings and return to the SharkClean app.



Questions?

Two Easy Steps If You're Stuck:
 Having trouble connecting to your robot? Call **1-888-228-5531** for robot support.

For additional help, visit: sharkclean.com/support

- How-to Videos
- FAQs
- Troubleshooting
- Tips & Tricks

Smart Home Setup

To set up voice control using Google Home or Amazon Alexa, visit sharkclean.com/app for instructions.

HAVING TROUBLE CONNECTING TO YOUR ROBOT?
Restart your phone
Reboot your robot

- Press the power button on the side of the ROBOT for 10 seconds to the OFF position, then press it again to turn power back ON.

Reboot your router

- Unplug the router power cable for 30 seconds, then plug it back in. Allow several minutes for your router to reboot completely.