



# RAZER TETRA

MASTER GUIDE

The **Razer Tetra** is a single-ear console chat headset designed for you to enjoy audio from your television setup while communicating with teammates. Comfortably light at just 70g, it packs a rotatable cardioid microphone for optimal voice-pickup. Be heard loud and clear in the heat of battle.

# CONTENTS



1. WHAT'S INSIDE / WHAT'S NEEDED.....	3
2. LET'S GET YOU COVERED.....	4
3. TECHNICAL SPECIFICATIONS.....	5
4. USING YOUR HEADSET .....	6
5. SAFETY AND MAINTENANCE .....	7
6. LEGALESE.....	8

---

## 1. WHAT'S INSIDE / WHAT'S NEEDED

### WHAT'S INSIDE

- Razer Tetra gaming chat headset



- A. Adjustable headband
- B. Leatherette ear cushion
- C. Foldable unidirectional microphone with mic foam
- D. Volume control wheel
- E. Microphone mute toggle
- F. 3.5 mm audio + mic connector

- Important Product Information Guide

### WHAT'S NEEDED

Audio + microphone usage


- Devices with 3.5 mm audio + mic combined jack\*

*\*Audio splitter (not included) may be required for PCs with separate audio output and microphone input jacks.*

---

## 2. LET'S GET YOU COVERED

You've got a great device in your hands, complete with a 2-year limited warranty coverage. Now maximize its potential and score exclusive Razer benefits by registering at [razerid.razer.com](https://razerid.razer.com)



Got a question? Ask the Razer Support Team at [support.razer.com](https://support.razer.com)

---

## 3. TECHNICAL SPECIFICATIONS

### HEADPHONES

- Frequency response: 20 Hz – 20 kHz
- Impedance: 32  $\Omega$  @ 1 kHz
- Sensitivity (@1 kHz): 107 dB
- Drivers: 32 mm, with Neodymium magnets
- Connection type: Analog 3.5 mm
- Cable length: 1.3 m / 4.27 ft.
- Approx. weight: 70 g / 0.15 lbs
- On ear cushions: Leather with soft foam

### MICROPHONE

- Frequency response: 100 Hz – 10 kHz
- Signal-to-noise ratio: > 55 dB
- Sensitivity (@1 kHz):  $-41 \pm 3$  dB
- Pick-up pattern: Unidirectional ECM boom

### IN-LINE CONTROL


- Analog volume control wheel
- Microphone quick mute toggle

---

## 4. USING YOUR HEADSET

### MUTING THE MICROPHONE

Slide the microphone mute toggle to mute or unmute the mic.




Unmute

Mute

### ADJUSTING THE VOLUME

Rotate the volume control wheel clockwise or counterclockwise to increase or decrease the audio output volume.



Increase volume

Decrease volume

---

## 5. SAFETY AND MAINTENANCE

### SAFETY GUIDELINES

In order to achieve maximum safety while using your Razer Tetra, we suggest that you adopt the following guidelines:

Should you have trouble operating the device properly and troubleshooting does not work, unplug the device and contact the Razer hotline or go to [support.razer.com](https://support.razer.com) for assistance.

Do not take apart the device (doing so will void your warranty) and do not attempt to operate it under abnormal current loads.

Stretch the headband gently apart before placing them over your head to minimize headband stress. However, please avoid overstretching the headset beyond its technical limits.

Keep the device away from liquid, humidity or moisture. Operate the device only within the specific temperature range of 0°C (32°F) to 40°C (104°F). Should the temperature exceed this range, unplug and/or switch off the device in order to let the temperature stabilize to an optimal level.

The device isolates external ambient sounds even at low volumes, resulting in lowered awareness of your external surroundings. Please remove the device when engaging in any activities that requires active awareness of your surroundings.

Listening to excessively loud volumes over extended periods of time can damage your hearing. Furthermore, legislation of certain countries permits a maximum sound level of 86dB to affect your hearing for 8 hours a day. We therefore recommend that you reduce the volume to a comfortable level when listening for prolonged periods of time. Please, take good care of your hearing.

### MAINTENANCE AND USE

The Razer Tetra requires minimum maintenance to keep it in optimum condition. Once a month we recommend you unplug the device and clean it using a soft cloth to prevent dirt buildup. Do not use soap or harsh cleaning agents.



---

## 6. LEGALESE

### **COPYRIGHT AND INTELLECTUAL PROPERTY INFORMATION**

©2019 Razer Inc. All rights reserved. Razer, the triple-headed snake logo, Razer logo, “For Gamers. By Gamers.”, and “Powered by Razer Chroma” logo are trademarks or registered trademarks of Razer Inc. and/or affiliated companies in the United States or other countries. All other trademarks and trade names are the property of their respective owners and other company and product names mentioned herein may be trademarks of their respective companies.

Razer Inc. (“Razer”) may have copyright, trademarks, trade secrets, patents, patent applications, or other intellectual property rights (whether registered or unregistered) concerning the product in this guide. Furnishing of this guide does not give you a license to any such copyright, trademark, patent or other intellectual property right. The Razer Tetra (the “Product”) may differ from pictures whether on packaging or otherwise. Razer assumes no responsibility for such differences or for any errors that may appear. Information contained herein is subject to change without notice.

### **LIMITED PRODUCT WARRANTY**

For the latest and current terms of the Limited Product Warranty, please visit [razer.com/warranty](https://www.razer.com/warranty).

### **LIMITATION OF LIABILITY**

Razer shall in no event be liable for any lost profits, loss of information or data, special, incidental, indirect, punitive or consequential or incidental damages, arising in any way out of distribution of, sale of, resale of, use of, or inability to use the Product. In no event shall Razer’s liability exceed the retail purchase price of the Product.

### **GENERAL**

These terms shall be governed by and construed under the laws of the jurisdiction in which the Product was purchased. If any term herein is held to be invalid or unenforceable, then such term (in so far as it is invalid or unenforceable) shall be given no effect and deemed to be excluded without invalidating any of the remaining terms. Razer reserves the right to amend any term at any time without notice.