

HB40说明书 (helloworld)

说明书为折叠式
尺寸: 630*120MM
材质: 100g双胶纸 (彩色)
版本: V1.0
类型: 环保

版本	修改内容	日期
Ver: 1.0	首次发行.	2022/08/30

设计	审核	审批
王勇		
2022/08/30	2022/09/05	

630.00 mm

HelloBaby®

Ver: 1.0

User Manual

2.4GHz Digital Wireless Video Baby Monitor



Model#: HB40

The picture is for reference only, please subject to product.

www.hellobaby.net.cn
service@helloworld.net.cn

Thank you for purchasing the HelloBaby Monitor. With our baby monitor, you could see and hear your baby's response or playing in their room anytime.

Please retain your original dated sales receipt for your records. For warranty service of your product, you will need to provide a copy of your dated sales receipt to confirm warranty status. Registration is not required for warranty coverage.

Please make sure the following included in your package:

- Parent Unit x 1
- Camera Unit x 1
- Power Adapter x 2
- User manual x 1

1. SAFETY INSTRUCTIONS

CAUTION: Always be awake away from children.

Strangulation Hazard: Children have STRANGLING in cords. Keep this cord out of the reach of children (more than 3ft (0.9m) away). Never use extension cords with AC Adapters. Only use the AC Adapter provided.

Choking hazard: This product contains small parts, please be careful when unpack and assemble the product.

Read and keep to instructions: All the safety and operating instructions should be read and follow the video baby monitor is required. This product cannot replace responsible adult supervision.

Water and moisture: This product is designed for indoor use only. The units should not be exposed to rain, moisture, dripping or splashing. No objects filled with liquid should be placed on or beside the product, such as a glass or vase. This item should not be used near water.

DO NOT: Use the appliance if the cord or plug is damaged. If your baby monitor is not operating properly or has suffered any damage, contact "VideoMe" service center to request inspection and repair of the appliance in order to avoid any possible risk.

DO NOT: Do not attempt to repair or adjust any of the electrical or mechanical functions of the unit. Otherwise, the guarantee will be voided.

DO NOT: This baby monitor should not be used on a bed, sofa, rug or similar surface that you block the ventilation opening, or be placed in an enclosed area such as bookcase or drawers that may restrict air flow.

Keep away from sources of heat: This unit should not be exposed to direct heat sources such as candle, radiator, heat register, stove or other appliances that emit heat. The unit should not be left in direct sunlight.

Power Source: This unit should only be used with the AC power adapters included in this package (rated 5V DC 1A).

Damaging electrical service: This unit should be serviced by qualified personnel only when: Objects have fallen on or liquid has been spilled onto the product; The units have been exposed to rain.

The units do not appear to operate normally or exhibit a distinct change in performance. The units have been exposed to the product or the product is damaged.

2. WARRANTY TERMS

We offer one year warranty from the original date of purchase against defects in workmanship and material. If you have warranty or support issues, please contact our after sales service email.

3. INSTALLATION GUIDELINES

- 1. Place your parent unit and camera unit together, you have to establish a radio link between them, and the range will be affected by environmental conditions.
- 2. Any large metal objects, like a refrigerator, a mirror, a filing cabinet, metal doors or reinforced concrete between the baby and parent unit may block the radio signal.
- 3. The signal strength may be reduced by other related wireless, like wi-fi, or radio or electrical equipment, such as TV, computers, cordless or mobile phones, fluorescent lights or dimmer switches.
- 4. Use of other 2.4G Hz products, such as wireless network (Wi-Fi) routers, Bluetooth devices, or microwave ovens, may cause interference with this product. Use the baby monitor away at least 1ft (30cm) from such products, or turn them off if they cause interference.

4. PLACEMENT OF THE BABY MONITOR

The camera can be placed on the desk top or mounted on the wall. Don't place baby monitor on soft furniture (sofas or beds) corners or bedside, staircase, etc. Keep the baby monitor away from heat sources such as radiators, chimneys, heaters and direct sunlight. Keep the baby monitor away from TVs, hair, microwave ovens and radios. If interference occurs, move the camera to other area:

- 1. Place the camera within 5 feet (1.5 meters) of the area being monitored for optimum performance.

5. GETTING STARTED

5.1 TURN ON THE BABY UNIT:

1. Insert the DC power adapter into the DC jack on the rear of the Baby Unit.
2. Insert the other end of the power adapter into a suitable electrical outlet.
3. Once the adapter is connected, the power LED will light up.

5.2 TURN ON THE PARENT UNIT:

1. Insert the DC power adapter into the DC jack at the side of the Parent Unit.
2. Insert the other end of the power adapter into a suitable electrical outlet.
3. Press and hold the power key 3 seconds on the front of the parent unit.
4. Once parent unit is on, the power LED will light up and the image will display on the LCD.

6. PRODUCT OVERVIEW

6.1 ICONS OVERVIEW

6.2 PARENT UNIT OVERVIEW

6.3 INFRARED NIGHT VISION (AUTOMATIC)

The infrared night vision function allows the camera to pick up images in dark or low light conditions. In this mode, red and white images will be displayed on the monitor. The optimum image is when the baby unit is 1ft (30cm) away from the object. The camera in night vision mode, the icon will display on the top of screen.

6.4 ICONS OVERVIEW

6.5 BABY UNIT OVERVIEW:

7. KEY FUNCTIONS

7.1 TURN ON/OFF
Press the **POWER** key for 3 seconds to turn on/off the parent unit.

7.2 UP KEY
Press the **UP** key to adjust the camera down by one step. Press and hold to tilt continuously.

7.3 DOWN KEY
Press the **DOWN** key to adjust the camera down by one step. Press and hold to tilt continuously.

7.4 LEFT KEY
Press the **LEFT** key to rotate the camera left by one step. Press and hold to pan continuously.

7.5 RIGHT KEY
Press the **RIGHT** key to rotate the camera right by one step. Press and hold to pan continuously.

7.6 CAMERA WISDOM
Press icon to view/scan camera during streaming, the scan icon will be displayed on the top of screen. Each camera's view will be displayed on the LCD screen 10 seconds then change to next camera.

7.7 DIGITAL ZOOM
Press the **Zoom In** key around 2 seconds to operate zoom in/out.
Press the **Zoom Out** key around 2 seconds to operate zoom in/out.
Press and hold **Zoom In** key to view two way talk mode. A microphone icon will be displayed on the corner of the LCD screen. Release the key to stop.
Note: When you are in the two-way talk mode, the parent status bar is muted.

8. MENU OPERATION

8.1 PUSING THE CAMERA AND PARENT UNITS
The baby unit is pre-registered to your parent unit. You do not need to register it again unless the baby unit loses its link with the parent unit. To register your baby unit, register it.

9. CAMERA UNIT OPERATION

After the camera unit is powered on, you should select and pair with the camera icon within 30" of range.

9.1 ADD CAMERA
1. Press the **ADD** key until the menu will pop up.
2. Press the **UP** key to select the camera icon. **ADD** is selected by orange box.
3. Press **OK** key to enter into sub-menu, then press **UP** key to select your desired camera.
4. Press **OK** key to enter into sub-menu. **ADD** the process **OK** key.
5. When the icon **ADD** stop pad on the LCD screen, press the **Home** button on the back of camera.
6. Once paired, successful pairing icon **ADD** shows on the LCD screen.

9.2 DELETE CAMERA
1. Press the **DELETE** key and the menu will pop up.
2. Press the **UP** key to select the camera icon. **DELETE** is selected by orange box.
3. Press **OK** key to enter into sub-menu. **DELETE** the process **OK** key.
4. Press the **DELETE** key to delete the camera.
5. Press **OK** key to confirm the option.

9.3 VOLUME
1. Press the **VOLUME** key when the menu will pop up.
2. Press the **UP** key to select the volume icon. **VOLUME** is selected by orange box.
3. Press the **UP** key to enter into sub-menu.
4. Press the **UP** key to select the desired volume level from level 1~5.
5. Press **OK** key to confirm.

9.4 DISPLAY BRIGHTNESS
1. Press the **BRIGHT** key when the menu will pop up.
2. Press the **UP** key to select the brightness icon. **BRIGHT** is selected by orange box.
3. Press the **UP** key to enter into sub-menu.
4. Press the **UP** key to select the desired brightness level from level 1~5.
5. Press **OK** key to confirm.

9.5 TEMPERATURE UNIT SETTING
1. Press the **TEMP** key when the menu will pop up.
2. Press the **UP** key to select the temperature icon. **TEMP** is selected by orange box.
3. Press the **UP** key to enter into sub-menu.
4. Press the **UP** key to select the temperature icon. **TEMP** for setting temperature unit.
5. Press **OK** key to confirm.
6. Press **OK** key to confirm.

Note: The selected temperature range is 0~40 °C.

9.6 TEMPERATURE ALARM SETTING
1. Press the **TEMP** key when the menu will pop up.
2. Press the **TEMP** key to select the alarm icon. **TEMP** for turning on alarm function, Press **OK** key to confirm.
3. Press the **TEMP** key to select the alarm icon. **TEMP** for turning off alarm function, Press **OK** key to confirm.

9.7 LULLABY SETTING
This unit supports the lullaby song by playing a gentle lullaby from the Camera unit.

9.8 SET TEMPERATURE ALERT LIMITS
1. Press **TEMP** key to select **TEMP** or **TEMP** for alert limits settings.
2. Press **TEMP** key to adjust the set limit when **TEMP** is selected.
Note: The high temperature alarm default setting is 36 °C, and the low temperature alarm default setting is 18 °C. When the temperature goes above or below the settings, the temperature icon will vibrate on the screen. It will alert you by beep. Press any key on the parent unit to stop ringing and flashing.

9.9 LULLABY SETTING
This unit supports the lullaby song by playing a gentle lullaby from the Camera unit.

1. Press the **LULLABY** key and the menu will pop up.
2. Press the **LULLABY** key to select the lullaby icon. **LULLABY** is selected by orange box.
3. Press the **LULLABY** key to select one of the 6 available lullabies, you can press single playback, repeat or stop lullaby settings **OK**.
4. Press **OK** key to confirm.

9.10 BREATHING TIME
1. Press the **BREATHING** key and the menu will pop up.
2. Press the **BREATHING** key to select the alarm icon. **BREATHING** is selected by orange box.
3. Press the **BREATHING** key to set the alarm limit for 1 minute. After three minutes, the alarm will ring again to control the sound until you press a key on the screen of the parent unit. When the baby unit detects any sounds louder than the sensitivity level, the alarm will stop for 5 seconds. The maximum setting is 3 hours (30 levels).

Note 1: When the alarm is started on, alarm icon **BREATHING** will display on the screen.

Note 2: When the alarm is ringing, press any key on the parent unit to stop the alarm off.

Note 3: The alarm default setting is OFF.

Note 4: When the alarm is ringing, press any key on the screen for 1 minute. After three minutes, the alarm will ring again to control the sound until you press a key on the screen of the parent unit.

9.11 SLEEP MODE
This mode allows you to control the sound activity of your baby unit. If there is no sound in the baby unit within 30 seconds, it will stop audio transmission and turn off the screen of the parent unit. When the baby unit detects any sounds louder than the sensitivity level, the screen will turn on.

level, it will start transmitting the signal to the parent unit again and on the screen of the parent unit, to change the VGA level, please follow the below instructions:

1. Press the **HOME** key until the menu will pop up.
2. Press the **TEMP** key to select the temperature icon. **TEMP** is selected by orange box.
3. Press **OK** key to enter into sub-menu, then press **UP** key to select desired level.
4. Press **OK** key to confirm.

Note: **TEMP** is high sensitivity level, the baby have to make a lot of sound before the VGA level will be activated.

Note: **TEMP** is middle sensitivity level.

Note: **TEMP** is high sensitivity level, the baby don't have to make a lot of sound before the VGA level will be activated.

READ SETTING

1. Press the **HOME** key and the menu will pop up.
2. Press the **TEMP** key to select the temperature icon. **TEMP** is selected by orange box.
3. Press the **TEMP** key to enter into sub-menu, then press **UP** key to select the key, then select any key setting.
4. Press **OK** key to enter into sub-menu, then press **UP** key to select the key, then select any key setting.
5. Press **OK** key to enter into sub-menu, then press **UP** key to select the key, then select any key setting.
6. Press **OK** key to confirm.

RAMING SETTING

1. Press the **HOME** key and the menu will pop up.
2. Press the **TEMP** key to select the temperature icon. **TEMP** is selected by orange box.
3. Press the **TEMP** key to enter into sub-menu, then press **UP** key to select the key, then select any key setting.
4. Press the **TEMP** key to enter into sub-menu, then press **UP** key to select the key, then select any key setting.
5. Press the **TEMP** key to enter into sub-menu, then press **UP** key to select the key, then select any key setting.
6. Press **OK** key to confirm.

10. TECHNICAL DATA

Frequency	2403.5-2475.5MHz
Power Adapter	Parent Unit: Input: 100~240VAC 50/60Hz; Output: 5V DC 1A Camera Unit: Input: 100~240VAC 50/60Hz; Output: 5V DC 1A
Operating Range	Up to 1000ft (300m) indoor (line of sight) Up to 1000ft (300m) outdoor
Display	4.0" IPS TFT LCD
Battery (Parent Unit)	Li-ion 3.7V 2000mAh (17.4Wh)
Camera Unit	Li-ion 3.7V 1200mAh
Warmup time	<150Sec
Operation Environment	Operation Temperature: +32°~+104° (0°C~40°C) Maximum Operating Temperature: +59°~+104° (15°C~40°C)

10. PROBLEMS SHOOTING

10.1 No connection on monitor

1. The power indicator may not properly connected.
2. Confirm that the camera and parent unit are ON.
3. Camera may be away from the parent.
4. Camera may be too far from the parent. Move it within 10m from the parent.
5. Remove the obstacle between camera and parent.

10.2 Interference or poor reception

1. The camera or monitor may be placed too close to any metal objects.
2. Any electronic device may be interfering with the signal.
3. The camera or monitor may be placed too close to any metal objects.
4. The camera or monitor may be placed too close to any metal objects.

10.3 Audio feedback (High pitched noise)

1. The camera or monitor may be placed too close to the parent unit.
2. The camera or monitor may be placed too close to the parent unit.

10.4 Power Flicker on Screen

1. Adjust that the baby unit is not too close to the parent unit.
2. Press the **HOME** key at the back of parent unit.

11. MAINTENANCE

1. Clean your baby monitor with a slightly damp and anti-static cloth.
2. Never clean clothing, agents or chemicals.

12. DISPOSAL GUIDE FOR BATTERY AND PRODUCT

1. Do not attempt to repair or adjust any of the electrical or mechanical functions of the units.
2. Remember to dispose of the product in an environmentally responsible way.
3. For proper collection and processing of these products, take them to the collection points designated by local authorities. You can also contact the store where you purchased the product.

13. SAFETY INFORMATION

Improper or incorrect use of batteries may cause corrosion or battery leakage, which could cause personal injury or damage to property. Use only the types of batteries which are indicated in the manual.

CAUTION: Risk of Fire and Burn. Do Not Open, Crush, Heat above 45 degree C or Incinerate. Follow Manufacturer's Instructions.

Disposal of a battery into fire or other, or mechanically crushing or cutting of a battery, can cause fire or an explosion.

Leaving a battery in a suitably high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas.

A battery is subjected to a self-heating power procedure that may result in an explosion or the leakage of flammable liquid or gas.

The battery shall not be exposed to excessive heat such as sunlight, fire or the like.

14. FCC CLASSIFICATION

This device complies with Part 15 of the FCC Rules and Industry Canada License exempt RSS (Standard). Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation. Cet appareil est conforme à la partie 15 des règles de la FCC aux normes RSS exemptes de licence d'Industrie Canada. Le fonctionnement est soumis aux deux conditions suivantes: (1) Cet appareil ne peut pas causer d'interférence nuisible et (2) Cet appareil doit accepter toute interférence reçue, y compris les interférences provenant d'autres équipements radio.

15. CE MARKING

Conformément à la directive CE, ce produit est conforme aux exigences de la directive CE. Les informations relatives à la conformité CE sont disponibles sur le site Internet de la Commission européenne.

16. PRODUCT COMPLIANCE

This device complies with Part 15 of the FCC Rules and Industry Canada License exempt RSS (Standard). Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation. Cet appareil est conforme à la partie 15 des règles de la FCC aux normes RSS exemptes de licence d'Industrie Canada. Le fonctionnement est soumis aux deux conditions suivantes: (1) Cet appareil ne peut pas causer d'interférence nuisible et (2) Cet appareil doit accepter toute interférence reçue, y compris les interférences provenant d'autres équipements radio.

17. PRODUCT COMPLIANCE

This device complies with Part 15 of the FCC Rules and Industry Canada License exempt RSS (Standard). Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation. Cet appareil est conforme à la partie 15 des règles de la FCC aux normes RSS exemptes de licence d'Industrie Canada. Le fonctionnement est soumis aux deux conditions suivantes: (1) Cet appareil ne peut pas causer d'interférence nuisible et (2) Cet appareil doit accepter toute interférence reçue, y compris les interférences provenant d'autres équipements radio.

Information en français de l'ISED sur l'exposition aux RF: la limite OAS de Canada (SED) est de 0,08 W/kg moyennant un régime de dose. Toute exposition à la limite OAS de Canada est considérée comme étant sûre. Pour plus d'informations, consultez le site Web de l'ISED: www.ISED.gc.ca. Toute exposition à la limite OAS de Canada est considérée comme étant sûre. Pour plus d'informations, consultez le site Web de l'ISED: www.ISED.gc.ca.

EU Declaration of Conformity (DoC)

Product: VideoMe Baby Monitor. The radio equipment type is in compliance with RED Directive 2014/53/EU. The full text of the declaration of conformity is available on the website: www.hellobaby.net.cn

Model: HB40
Responsible Party: Startline Inc.
Address: 242 Woodbine Drive, Toronto, ON M1S 1Y3, Canada
Tel: 1-888-663-3729
Email: info@startline.com
Website: www.startline.com
Startline VideoMe Technology Co., Ltd.
701, Building 3, No. 2 Zhenhua Road, Gaosheng Community, Jinhua Street Office, Longgang District, Shenzhen

WARNING! If emitted from this Risk Group 1 Product, do not stare at operating lamp. Product tested against EN62471.

WARNING

Strangulation Hazard: Children have STRANGLING in cords. Keep this cord out of the reach of children (more than 3ft (0.9m) away). Do not remove this tag.

AVERTISSEMENT

DANGER D'ÉTRANGLEMENT: Des enfants se sont ÉTRANGLÉS avec des cordons électriques. Gardez le cordon électrique hors de la portée des enfants (plus de 3 pi ou 1 m de l'enfant). Ne pas enlever cette étiquette.

CE **UK** **RoHS** **RECYCLE** **WEEE** **SAFETY**

Information en français de l'ISED sur l'exposition aux RF: la limite OAS de Canada (SED) est de 0,08 W/kg moyennant un régime de dose. Toute exposition à la limite OAS de Canada est considérée comme étant sûre. Pour plus d'informations, consultez le site Web de l'ISED: www.ISED.gc.ca. Toute exposition à la limite OAS de Canada est considérée comme étant sûre. Pour plus d'informations, consultez le site Web de l'ISED: www.ISED.gc.ca.

EU Declaration of Conformity (DoC)

Product: VideoMe Baby Monitor. The radio equipment type is in compliance with RED Directive 2014/53/EU. The full text of the declaration of conformity is available on the website: www.hellobaby.net.cn

Model: HB40
Responsible Party: Startline Inc.
Address: 242 Woodbine Drive, Toronto, ON M1S 1Y3, Canada
Tel: 1-888-663-3729
Email: info@startline.com
Website: www.startline.com
Startline VideoMe Technology Co., Ltd.
701, Building 3, No. 2 Zhenhua Road, Gaosheng Community, Jinhua Street Office, Longgang District, Shenzhen

WARNING! If emitted from this Risk Group 1 Product, do not stare at operating lamp. Product tested against EN62471.

Made in China