

# Voyager Quadcopter

## Getting Started Guide

### 1. UNPACK

Unpack the Cocoon Voyager Quadcopter from the packaging and check you have all the components:


- 1 x Voyager Quadcopter
- 1 x Remote Control
- 4 x Replacement Propellor Blades
- 4 x Blade Guards
- 1 x Screwdriver
- 1 x USB Charging Cable
- 4 x ActivEnergy AA Batteries
- 1 x Instruction Manual
- 1 x Getting Started Guide
- 1 x Warranty Card



### 2. CHARGE BATTERY


1. Switch the Voyager Quadcopter off and open the battery cover.
2. Pull the battery wire out of the power port and remove battery.
3. Plug the battery wire into the smaller end of the USB charging cable.
4. Connect USB cable to an active USB port.

*Note: A full charge will take roughly 75 minutes*



### 3. INSERT BATTERIES

1. Remove the screw from the back of the remote control and remove the battery cover.
2. Insert 4 x AA batteries (taking note of polarity) and replace battery cover.
3. Reverse the steps in Section 2 to reconnect the battery to the Voyager Quadcopter.





# Voyager Quadcopter

## Getting Started Guide

### 4. TURN ON THE VOYAGER QUADCOPTER AND PAIR REMOTE CONTROL

1. Set the switch on the Voyager Quadcopter to "On" and place it on a flat, horizontal surface.
2. On the remote control, set the power switch on the front to the "On" position.
3. Push the left control stick to the highest position until you hear the remote control beep, then pull down to the lowest position until you hear another beep.


*Note: When successfully paired, the lights on the Voyager Quadcopter will stop flashing and change to solid colours*




### 5. FLY

*Note: Incorrect operation of this Voyager Quadcopter may result in severe injury, loss of property or fines. Winplus Australasia does not take any responsibility if local rules and regulations are not followed.*


*Note: The best way to know which direction the Voyager quadcopter is facing is by the coloured LEDs on it's wings. The red lights will face forwards, while the green lights face backwards. Always keep the Voyager Quadcopter in direct line of sight.*




Hover up and down  
Push the left control stick up or down.  
The Voyager Quadcopter will fly upward or downward.



Forward and backward  
Push the right control stick up or down. The Voyager Quadcopter will fly forward or backward.



Turn left and right  
Push the left control stick left or right.  
The Voyager Quadcopter will turn left or right.



Sideward fly  
Push the right control stick left or right.  
The Voyager Quadcopter will fly left or right.

### 6. FURTHER INSTRUCTIONS

For further flying instructions, as well as advanced techniques, please refer to the instruction manual provided.