

## Car Wireless FM Transmitter User Manual

### **Product Features**

- Plugging the device into car cigarette lighter, then it will turn on automatically: when it is in working state, the screen will display the voltage of car battery and monitor the car battery in any time.
- 2. Noise and wind suppressed by CVC technology to create full duplex sound quality 3. Support mobile's A2DP function. Music can be played
- directly while the mobile phone is connected.
- 4. Mobile phone can be connected automatically when the device turns on.
- 5. Support an external TF card, which can play music files in MP3/WMA format.
- 6. Integrated car charger function and its output is 5V/2.1A. which is available for charging handheld device.

### **Operation Instructions**

- 1. Power-On (1) Device turns on automatically when plugging it into
- cigarette lighter.
- as that of the device.
- (2) Select a blank channel. (3) Turn on car FM stereo and adjust the frequency same

click to connect it.

5. Playing Music from Mobile Phone (1) Once it connects successfully, music can be transferred

6. Switching Music File Sources

(1) It can play the music from TF card and the device with Wireless function: you can switch the file source between TF card and device with Wireless by long press >>>

Previous/Next song through both your phone and the

### Making a Call

(1) You can make and answer a call through this device after connecting with Wireless

(2) Double click (a) to redial the last number.

(3)Reject a call: Long press (a) for about 5 seconds to reject a call.

AUX cable.

8. AUX Input/Output (1) AUX Input: This device supports Line-in function, which can play music from MP4, CD, etc, via the 3,5mm AUX

(2) AUX Output: It can output audio to speaker, car stereo

and portable earphone through the 3.5mm AUX port by a

(3) This device has memory function. It will automatically connect to the previous connected devices when power on

# (4) If you want to remove the memorized devices, please

## press and hold the Frequency button to remove.

2. Frequency and Volume Adjustment

(2) Adjust the volume by rotating

3. Playing Music from TF Card

4. Connection to Wireless Devices

next/previous song.

(1) The frequency of this device is available from 87.5 -108.0 MHz, which can be adjusted by CH+ and CH- button.

(1) Insert the TF card into the device, it will automatically

detect and play the MP3/WMA/WAV format music in the TF

(2) Music selection: press >>> and |<>>> button to switch to

(1) This device is equipped with build-in Wireless chip.

(2) The pairing state will be activated automatically when

you can search wireless model "T10" with your phone and

which can connect to other handheld. Wireless, devices,

the device is powered on with the blue light flashes. Then

from phone to the car stereo.

(2) You can control Volume +/ - , Play/Pause,

## Frequency Line-in Port TF card slot Frequency + Next Sona Multifunction Button/Volume +/ Power Anode Power Cathode **USB Charging Port** Note: This device is compatible with most mobile

Product features will be upgraded without any notice.

9. Part Description

## Instruction 1. How to pair mobile Previous Sona 2. How to play and pause Display 3. How to adjust volume

Operation

rotatong 🔕 Press CH+ and CH - to 4. How to set frequency adjust frequency Press button to play next 5. How to select Press | button to play music

**FM Transmitter** 

liahterpower

Plug the device to cigarette

Press 🔕 button to play,

press again to pause

set Adjust the volume by

answer an incoming call.

previous song Press Dutton shortly to

Press 🔕 button to shortly stop 6. How to answer and stop a call the call during call answering Press (6) button longer during calling to refuse call double

phone No. during no calling 7. Switching mode long tap | last for 5s, then it phones, except of a few mobile phones that are not available will switch to TF card or to use parts of the above function. Bluetooth mode.

Sensitivity: -42db+ / 3 db 360

Wireless Version: V3 0 + FDR

Wireless

Voltage: 5 v + / -0.5 Working Current: 45mA (Max) Stand-by Current: 25mA (Max) Frequency: 2.4 GHz Effective Range: 5 Meters Sensitivity: -92 dBm RF Output: 4 dBm

Frequency: 87.5MHz -108.0MHz Transmitted Power: 87 dBuy / 107 dBuy Effective Range: 2 Meters

voltage damage

1. First of all, a blank FM channel must be chosen for car.

radio, then the frequency of T10 should be adjusted as the same as the frequency of car radio.

2. After a long time use, your car speaker may have some troubles. Therefore, please don't turn up car speaker's volume to maximum to avoid static and distortion effectively. 3. When the device is out of use for a long time, please pull Press button to recall last it out of cigarette lighter. When using again, it should be inserted into cigarette lighter after car starts to avoid high

MADE IN CHINA

@ (€ F© 💉