




EON ONE PRO

BATTERY POWERED | ONE HAND CARRY | BLUETOOTH AUDIO | LEGENDARY JBL SOUND


QUICKSTART GUIDE

1. LISTENING CONFIGURATIONS




1

Speaker Only



2

1 Spacer



3

2 Spacers

2. CHARGE THE UNIT

1. Confirm the **Power Switch (J)** is in the OFF position.
2. Connect the power cord to the Power Receptacle on the rear of the speaker.
3. The **Battery Level Meter (L)** will illuminate, indicating the unit is charging.
4. The unit is charged when the **Battery Level Meter (L)** is fully illuminated when powered on or off.

3. PLUG IN THE INPUTS

1. Turn the **Channel Volume Controls (F)** and **Master Volume Control (N)** all the way to the left before connecting any inputs.
2. Connect your device(s) via the input jacks provided.
3. If CH1 – CH4 inputs are being used, select MIC or LINE via the **Mic/Line Button (E)**.
4. If connecting instruments directly to inputs 3 – 4, engage the **Hi-Z button (Q)**.

4. POWER ON THE UNIT

1. Flip on the **Power Switch (J)**; the **Power LED (K)** and the Power LED on the front of the speaker will illuminate.

6. SET OUTPUT LEVEL


1. Set the **Channel Volume Controls (F)** to 12 o'clock.
2. Slowly turn the **Master Volume Control (N)** to the right until the desired volume is reached.
3. Fine tune the **Channel Volume Controls (F)** for the desired mix balance.
4. Enjoy your audio!

5. BLUETOOTH AUDIO

This device supports Bluetooth audio streaming.

To connect your device:

1. Turn on Bluetooth on your source device.
2. Press the **Bluetooth Pair Button (O)**.
3. Find JBL EON ONE PRO on your device and select.



Please visit <http://www.jblpro.com/Microsite-EONONE-pro> for complete documentation.

JBL Professional 8500 Balboa Blvd. Northridge, CA 91329 USA

© 2017 Harman International Industries, Incorporated