















## WARRANTY & DISPOSAL Warranty The guarantee period is 2 years from date of purchase. Proof of purchase required. Disposal The appliance must be disposed of properly. The appliance can be disposed of free of charge for at electrical dealers. This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision. Please make sure to place the appliance on a suitable and waterproof surface, so that spilled liquids can not cause damage.



