Megawise

KITCHEN SCALE



INSTRUCTION MANUAL

INSPIRE BRIGHTER LIVING

FOREWORD

In order to let you know and use the product better, and to ensure the accuracy of weighing and extend the life of the scale, please read this manual carefully before use.

If there is anything you don't understand, you can always consult, thank you for your cooperation!

BASIC PRODUCT FEATURES

- This product uses high-precision sensors and high-performance CPU, accurate and reliable weighing.
 LCD blue background showing white words
- Overload prompt, automatic shutdown, hold reading function, etc.
- With unit transfer switch
- 5. Super tempered glass panel support

TECHNICAL PARAMETERS AND IMPLEMENTATION STANDARDS

Product Name: Kitchen Scale Product model: K7H

Power supply mode: 2 × 1.5V AAA

Notice:

USB output voltage and current.

Voltage:5V /Current:1A

Weighing range: 3g----15000g Accuracy: 1g Product error: ± 2%+1g

BATTERY INSTALLATION METHOD





2AAA


The kitchen scale contains a built-in battery, When the battery runs out, you can use 2 AAA battery or USB cable to charge.

DISPLAY DESCRIPTION



1

KEY FUNCTION



1. "ON/OFF" button: It can be turned on and off. In the off state, press the "ON/OFF" button to turn it on. In the power on state, press and hold the "ON/OFF" button to turn it off.

2. "TARE" button: Place the carrier under the scale body (if there is a carrier tray), press the "TARE" button to perform the tare operation. The scale can be weighted after the zero is displayed.

3. "UNIT" button: This product has a variety of units for users to choose, press: "UNIT" button

for cycle selection

WEIGHING INSTRUCTIONS

- Place the product on a hard horizontal surface.
- 2. Place the carrier on the scale.
- 3. Press the "ON/OFF" button to turn it on. After powering on, press "ON/OFF" to turn it off.
- 4. Wait for the display to display "0" before you can start weighing. Press the "UNIT" button to perform unit conversion. Specifically, there are five conversion units as follows.



5. Tare function: The object is placed on the scale body (or on the load plate) for weighing, and the LCD screen will display the weight of the object. If the container is placed on the glass table, the LCD will display the weight of the container. Press the "TARE" button to peel the skin, the LCD will enter the clear state, and the object to be weighed will be placed in the container. The LCD display is the weight of the object.









USE SUGGESTIONS

1. Display "Er" means that the maximum weighing weight is exceeded.



2. The "LO-" flashing indicates that the battery is low. Please replace the battery in time.



AUTOMATIC SHUT-DOWN

The product will automatically shut down if there is no button operation or the weight changes within about 2 minutes.

PRECAUTIONS

- 1. Place the scale on a clean, level surface during use.
- 2. The weighing scale of the scale is 15000g maximum, including the weight before peeling.
- 3. Do not use this product in a humid, hot, cold place.
- This product belongs to high-precision electronic products. Please do not press hard on the scale body to prevent falling damage when moving.
- This product is only for household weighing items, and should not be used for commercial settlement, measurement, etc.
- When there is smudge on the scale of the product, wipe it with a soft cloth, do not use chemical reagents and prevent water from entering the scale body.
- 7. Please remove the battery when not in use for a long time.
- 8. When the LCD display shows "LO", the battery is too low, Please replace the battery in time.
- When the LCD display shows "Err", the item is overweight. Please remove the item in time to avoid damage to the product (the maximum range of the product is 15000g)

CUSTOMER SERVICE

Our customer service team is standing by to assist you if you have any questions or concerns.

Scan the QR-code to start chatting (live chat):



Scan QR Code & Start Chatting Or visit.



- m.me/MegaWiseUSA
- support@megawise.com
- megawise.com





