Yealink

MCore




English | 简体中文

Quick Start Guide (V1.0)




Package Contents



We recommend that you use the accessories provided or approved by Yealink. The use of unapproved third-party accessories may result in poor performance.


MCore Connection



- When starting up the MCore for the first time, you need to connect a mouse to complete the initial configuration. We recommend that you use the wireless mouse and keyboard kit.
 - MCore itself has integrated cable lock feature, and no additional cable lock box is needed to lock the cable.

MCore Installation

· Mount on the Wall



Before mounting the bracket, you need to confirm the direction of the MCore installation. Once the bracket is mounted, the installation direction of the MCore cannot be changed.

· Stick to the Table



You can stick the MCore on the top, sides or bottom of the table.


- 2

包装清单



我们推荐使用由Yealink提供或经Yealink认可的配件和线缆,使用未经认可的第三方配件和线缆可能会导致性能的下降。


连接MCore



- MCore已集成锁线功能,不需要额外的锁线盒来锁住线缆。

安装MCore

・挂墙



☑ 固定挂墙架前,需确认MCore要安装的方向,挂墙架一旦固定,MCore的安装方向随之固定。

· 固定在桌子上



MCore可贴在桌子的表面,两侧或底部。

ī

Regulatory Notices

Operating Ambient Temperatures

- Operating temperature: +32 to 104°F (0 to 40°C)
- Relative humidity: 5% to 90%, nonci • Storage temperature: -22 to +160°F (-30 to +70°C)

Warranty

Our product warranty is limited only to the unit itself, when used normally in accordance with the operating instructions and the system environm We are not liable for damage or loss resulting from the use of this product. or for any claim from a third party. We are not liable for problems with Yealink device arising from the use of this product; we are not liable for financial damages, lost profits, claims from third parties. etc... arising from

the use of this product. Explanation of the symbols

- DC symbol
- is the DC voltage symbol

 WEEE Warning symbol To avoid the potential effects on the environment and human health

alactronic aguinment, and users of electrical and electronic equipment should understand the meaning of the crossed-out wheeled bin symbol. Do not dispose of WEEE as unsorted municipal waste and have to collect such WEEF senarately

Bestriction of Hazardous Substances Directive (BoHS) This device complies with the requirements of the EU RoHS Dir Statements of compliance can be obtained by contacting support@vealink.com

Safety Instructions Save these instructions. Read these safety instructions before use!

 General Requirements Before you install and use the device, read the safety instructions

carefully and observe the situation during operation. During the process of storage, transportation, and operation, please

always keep the device dry and clean, avoid collision and crash Please attempt not to dismantle the device by yourself. In case of any discrepancy, please contact the appointed maintenance center for repair Please refer to the relevant laws and statutes while using the device

Legal rights of others should be respected as well. i Environmental Requirements

Place the device at a well-ventilated place. Do not expose the device under direct sunlight.

Keep the device dry and free of dusts

Do not place the device on or near any inflammable or fire-vulnerable object, such as rubber-made materials Keep the device away from any heat source or bare fire, such as a candle

or an electric heater.

Operating Requirements

- Do not let a child operate the device without guidance
- Do not let a child play with the device or any accessory in case of accidental swallowing
- Please use the accessories provided or authorized by the manufacturer only The power supply of the device shall meet the requirements of the input voltage of the device. Please use the provided surge protection power
- socket only Before plugging or unplugging any cable, make sure that your hands are completely dry
- Do not spill liquid of any kind on the product or use the equipment near vater, for example, near a bathtub, washbowl, kitchen sink, wel basement or near a swimming pool

- . During a thunderstorm, stop using the device and disconnect it from the ower supply. Unplug the power plug and the Asymmetric Digital Subscriber Line (ADSL) twisted pair (the radio frequency cable) to avoid lightning strike
- If the device is left unused for a rather long time, disconnect it from the power supply and unplug the power plug.
- When there is smoke emitted from the device, or some abnormal noise or smell, disconnect the device from the power supply, and unplug the power plug immediately.
- Contact the specified maintenance center for repair Do not insert any object into equipment slots that is not part of the
- product or auxiliary product. Before connecting a cable, connect the grounding cable of the device first. Do not disconnect the grounding cable until you disconnect all other

Cleaning Requirements

Before cleaning the device, disconnect it from the power supply Use a piece of soft, dry and anti-static cloth to clean the device

Keep the power plug clean and dry Troubleshooting

The unit cannot supply power to device other than Yealink device There is a bad connection with the plug

1. Clean the plug with a dry cloth 2 Connect it to another wall outlet

The usage environment is out of operating temperature range

 Use in the operating temperature range The cable between the unit and the Yealink device is connected incorrectly. 1 Connect the cable correctly

You cannot connect the cable properly You may have connected a wrong Yealink device. Use the correct power supply

Some dust, etc., may be in the por 1. Clean the port.

Contact your dealer or authorized service facility for any further questions FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this

device must accept any interference received, including interference that may cause undesired operation. Any Changes or modifications not expressly approved by the party responsible

for compliance could void the user's authority to operate the equipment. IC Statement This device complies with Industry Canada's licence-exempt RSSs. Operation is

subject to the following two condit (1) this device may not cause interference; and (2) this device must accept any interference, including interference that may cause undesired operation of the device CAN ICES-3(B)

Le présent appareil est conforme aux CNB d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes

(1) l'appareil ne doit pas produire de brouillage; (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi même si le brouillage est susceptible d'en compromettre le

fonctionnement.NMB-3(B)

Contact Information

YEALINK NETWORK TECHNOLOGY CO.,LTD. 309. 3rd Floor, No.16. Yun Ding North Road, Huli District, Xia en City, Fujian, P.R. C YEALINK (EUROPE) NETWORK TECHNOLOGY B.V.

Strawinskylaan 3127, Atrium Building, 8th floor, 1077ZX Amsi Strawinskylaan 3127, Atnum Building, 8th 1001, 10772A Airtor
YEALINK (USA) NETWORK TECHNOLOGY CO., LTD
999 Peachtree Street Suite 2300, Fulton, Atlanta, GA, 30309, Made in China

About Yealink

Yealink is a global leading provider of enterprise communication and collaboration solutions, offering video conferencing service to worldwide enterprises. Focusing on research and development, Yealink also insists on innovation and creation. With the outstanding technical patents of cloud computing, audio, video and image processing technology, Yealink has built up a panoramic collaboration solution of audio and video conferencing by merging its cloud services with a series of endpoints products. As one of the best providers in more than 140 countries and regions including the US, the UK and Australia, Yealink ranks No.1 in the global market share of SIP phones shipments.

Technical Support

Visit Yealink WIKI (http://support.yealink.com/) for the latest firmware, guides, FAQ, Product documents, and more. For better service, we sincerely recommend you to use Yealink Ticketing system (https://licket.yealink.com/) to submit all your technical issues.





Web: www.yealink.com Copyright@2020 YEALINK(XIAMEN) NETWORK TECHNOLOGY CO.,LTD.All rights reserved.