Go to www.vtechphones.com to register your product for enhanced warranty support and the latest VTech product news.

VM3252 VM3252-2

Video Monitor





vtech

User's manual

Congratulations

on purchasing your new VTech product. Before using this product, please read Important safety instructions

This manual has all the feature operations and troubleshooting necessary to install and operate your new VTech product. Please review this manual thoroughly to ensure proper installation and operation of this innovative and feature rich VTech product.


For support, shopping, and everything new at VTech, visit our website at www.vtechphones.com.

What's in the box










Install the battery


The parent unit runs on rechargeable battery or AC power. To continuously monitor your baby, make sure you use both battery and AC power at the same time. With the battery alone, the parent unit can cordlessly run for a short time only.

- · Use only the battery supplied with this product · If the parent unit will not be used for a long time, disconnect and remove the battery to prevent possible leakage.
- Install the battery as shown below.




6NOTE

• Press down on the battery compartment cover to pull it out.



 Make sure the label THIS SIDE UP is facing up while inserting the battery.



Displays when talking back to the

Displays the sound level according

to the scales of loudness when there

II (1 to 2 bars) indicates low sound

moderate sound level detected by

|||||| (5 to 6 bars) indicates high

unit (e.g. baby crying loudly).

Displays when the parent unit

speaker volume is set to off.

sound level detected by the baby

level detected by the baby unit.

IIII (3 to 4 bars) indicates

is sound transmitted from the baby

baby units from parent unit.

||||||| 6-level sound indicator

the baby unit.

Replace the battery


To replace the battery, pull out the battery compartment cover, and then lift up the battery. Follow the steps above to install the new battery.

Connect and charge the

NOTES

- Use only the power adapters supplied with this
- Make sure the electrical outlets are not controlled by wall switches
- · The power adapters are intended to be correctly oriented in a vertical or floor mount position. The
- prongs are not designed to hold the plug in place if they are plugged into a ceiling, under-the-table or Make sure the parent unit, the baby unit and the
- power adapter cords are out of reach of children.

Connect the baby monitor





Charge the parent unit battery

When you have connected the parent unit and installed its battery for the first time or after power outage, the parent unit powers on automatically. The battery icon indicates the battery status (see the following table).

The battery

becomes

- The parent unit battery is fully charged after 11 hours of continuous charging.
- It takes longer to charge the battery when the parent unit is turned on. To shorten the charging
- time, turn the parent unit off while charging. The standby time varies depending on the volume level you set, your actual use and the
- age of the battery. Action Battery indicators status

			I
The battery icon is off and 3 displays.	No battery is installed but operates using AC power, or the battery has been installed incorrectly.	Install the parent unit battery. Charge without interruption (at least 30 minutes).	> More than 3 feet (1 meter)
The screen displays Battery low at Parent Unit and The light flashes.	The battery has very little charge and may be used for only a short time.	Charge without interruption (about 30 minutes).	1. Make sure your baby units and parent unit are on. 2. The parent unit displays images from the

The battery is | To keep

fully charged. | the battery

charged,

AC power

when not in

connect it to

2. The parent unit displays images from the baby unit. Speak towards the microphone of the baby unit. You will hear the sound at the

efore use

not be used as such

Test your baby monitor

use, and at regular times thereafter.

· This baby monitor is intended as an aid. It is not a

You may test the baby monitor before initial

For hearing protection, make sure the parent unit is more than 3 feet (1 meter) away from

both baby units. If you hear any high-pitched

noise stops. You can also press VOL- on the

noise, move the parent unit further until the

parent unit to lower or mute the noise.

substitute for proper adult supervision, and should

3. If you have two baby units, press CAM at the right side of your parent unit. The screen switches to other baby unit. Then, repeat

step 2.

• When the parent unit displays No link to Camera, and the **LINK** LED light flashes, move the parent unit closer to the baby units (observe the minimum distance of 3 feet/ 1 meter). You can also check if the baby monitor is connected to a live power socket and switched on.

 Increase the speaker volume of the parent unit if you cannot hear the sounds transmitted from the baby units.

Positioning the baby monitor

up to 1,000 feet (300 meters) outdoors or Keep the baby unit out of the reach of your baby. Never place or mount the baby unit inside the 160 feet (50 meters) indoors. The actual operating range may vary depending on the environmental conditions and other

baby's crib or playpen.


- · To avoid interference from other electronic devices, place your baby monitor far away from cell phones and computers.
- (1 meter) away from your baby.



aim at your baby.



(1 meter) away from the baby units.



() CAUTION

- The default volume of your parent unit is level 3, and the maximum volume is level 5. If you experience high-pitched screeching noise from your baby monitor while positioning:
- Make sure your baby units and parent unit are more than 3 feet (1 meter) apart, OR Turn down the volume of your parent unit.

1. Press **MENU** when the parent unit is idle. 2. Press ◀ or ▶ to choose 💵, then press ▲

activation

save power.

3. Press ▼ or ▲ to choose the desired sensitivity level, then press SELECT to confirm your selection.

* For VM3252-2 only

5. Press **SELECT** to confirm your selection.

If there are two baby units in your system, you can also monitor your baby in PATROL mode.

	The screen displays image of a single baby unit in full screen.
PATROL	A single cam view that transits to a different baby unit every 10 seconds.

To switch to another camera:

Press CAM to switch to another camera.



 If the sound sensitivity is set to the highest level, or lullaby is playing, the parent unit screen may

remain on continuously even though sound activation is on. This depends on whether the baby unit detects any sounds.

For parent unit: Press VOL-/VOL+ on the parent unit to

adjust the speaker volume.

 When the parent unit speaker volume is set to zero, I appears on the screen and the ☒ light


For baby unit:

The baby unit speaker volume determines the lullaby and talkback volume transmitted from

- 1. Press **MENU** when the parent unit is idle.
- Press ◀ to choose

The operating range of the baby monitor is · Your baby units and parent unit provided are already paired. **POWER LED light** · On when the baby unit is turned on. • Flashes when the baby unit is not interferences such as walls, doors and other being viewed; or when the link to the parent unit is lost. Microphone Camera Infrared LEDs Light sensor **் ON/OFF switch** Slide to turn on or off the baby unit.

Parent unit overview



1	Indicate the different statuses of the parent unit. For details, refer to Parent unit lights.
2	LCD display
3	Zoom Press to zoom in or out while viewing image.
4	 Press to change the screen to view images from different baby units. For VM3252-2 only
	LCD ON/OFF
	Press and hold to turn on or off the LCD screen.
5	MENU/SELECT

move the zoomed image upward. into the submenu, if any.

			to the main m
1	LED lights • Indicate the different statuses of		While zoomir move the zoo
	the parent unit. For details, refer to Parent unit lights .	8	On/off • Press and ho
2	LCD display		Press and ho
3	Press to zoom in or out while viewing image.	9	TALK • Press and ho selected baby
4	Press to change the screen to view images from different baby units.	10	VOL- • Turn down the speaker is on
	For VM3252-2 only LCD ON/OFF Press and hold to turn on or off the LCD screen.	11	VOL+ • Turn up the v speaker is on
5	MENU/SELECT	12	Speaker
•	Press to enter/exit the menu.	13	Power jack

move the zoomed image downward. While in a menu, press to choose the next item on the left, or enter While zooming, press and hold to move the zoomed image leftward. While in a menu, press to choose the next item on the right, or return menu while in submenu ing, <u>press and hold</u> to omed image rightward. old to power on. old again to power off. old to talk to the by unit. he volume when the volume when the Battery compartment cover

- While in a menu, press to scroll up, or to enter an item's sub-menu. While zooming, press and hold to
- While in a menu, press to scroll While zooming, press and hold to

- While in a sub-menu, press to choose an item, or save a setting. Stand

- - Ω on the parent unit has zoomed in. Night vision

- **LINK** On when the parent unit is linked to the baby unit.
 - baby unit is nearly lost. On when the parent unit is connected to AC power, or the attery is charging. Flashes when the parent unit
 - battery is low and needs charging. Off when the parent unit is disconnected from AC power.
 - parent unit is turned off. **TALK** On when the parent unit is talking to

Parent unit status icons

Connection status Yull or Yul displays when strong signal strength is detected between the baby unit and the parent unit.

• Yu or Yu displays when moderate

- or low signal strength is detected between the baby unit and the parent unit. Patrol mode
- Displays when the parent unit is in PATRÓL mode. For VM3252-2 only **2** 1or | Current view status · Displays the baby unit number of
- the baby unit that is being viewed. Displays when the current image
 - Displays when the baby unit being viewed has activated the night
- Displays when a lullaby is playing.

Parent unit lights

- Flashes quickly when the link to the
- On when the speaker volume of the
- the baby unit.

Real-time temperature Displays the real-time temperature detected by the baby unit in

■ Mute alert

- Fahrenheit (°F) or Celsius (°C) (e.g. **57°F** or **14°C**). Battery status > 1 animates
 - when the battery is charging. displays solid when the battery is fully charged. displays when the battery is low and needs charging.
- AC power without battery Displays when the parent unit is connected to AC power without the battery. Speaker volume

Displays the parent unit speaker

volume level while adjusting.

detects no sound, the parent unit screen stays off to save automatically. It will then turn


Patrol mode

PATROL mode.

For VM3252-2 only

messages


1.00
Brightness You can change the brightness of the parent unit screen.



Parent unit main menu icons




Temperature You can choose to set the maximum/ minimum temperature and turn on the temperature alert tone, so that the parent unit beeps whenever the room temperature detected by the baby unit falls outside of the desired temperature range. You an also choose to display the



You can select, play, or stop a

With this feature, you can choose to hear sounds from the baby unit all the time, or to hear sounds that exceed a certain level. You can use the parent unit to adjust the microphone sensitivity of your baby unit. The higher the sensitivity level, the more sensitive the baby unit is in detecting sounds for transmitting to the parent unit.



power. Once a sound is detected, the parent unit screen turns on off again after 50 seconds of no sound detection.

You can monitor your baby in

Parent unit warning icons and

No link to Camera	The link between the baby unit and the parent unit is lost.
/Battery low at Parent Unit	The battery is empty and needs to be recharged.
图	Operation is in progress.
/Temperature too high or /Temperature too low	The temperature detected by the baby unit is higher/ lower than the desired temperature alert range.
%	The parent unit is

searching for baby units.

Using the baby monitor

Power on or off the baby unit • Slide the **ON/OFF** switch down to turn on the baby unit. The **POWER** LED light turns

• Slide the **ON/OFF** switch up to turn off

the baby unit. The **POWER** LED light turns

The screen turns on. Press and hold again to turn off the parent unit. The screen turns off.

You can turn on or off the parent unit screen

 Press and hold LCD ON/OFF on the parent unit to turn off the screen.

unit when there is no key press for a specific time interval.

sound from the baby unit.

Press ◀ or ▶ to choose ■, then press ▲.

Adjust LCD brightness

unit screen from Level 1 to Level 5. The LCD brightness is preset to **Level 3**.

You can choose to hear sounds from the baby

Power on or off the parent unit Press and hold to turn on the parent unit.

Turn on or off the parent unit

Screen off timer You can set the screen off time for the parent

period to time off screen (5 / 50 / 60 /), then press SELECT to confirm your

You can change the brightness of the parent

1. Press **MENU** when the parent unit is idle. Press ◀ or ▶ to choose ♥, then press ▲.

unit all the time, or to hear sounds that exceed a certain level. You can use the parent unit to adjust the microphone sensitivity of your baby

for transmitting to the parent unit. The VOX

without powering off the parent unit. You can

Press any key on the parent unit to turn on the screen again.

1. Press **MENU** when the parent unit is idle.

· You can adjust the baby unit placement to

sound sensitivity is preset to the highest level.

still hear sound from the baby unit.

Adjust the sound sensitivity of the baby unit

unit. The higher the sensitivity level, the more sensitive the baby unit is in detecting sounds

Sensitivity Level		Description
Highest	High sensitivity	Highest VOX sensitivity level The parent unit speaker is constantly on, and you will hear all sounds (including background noises) from your baby's room.
High		High VOX sensitivity level The parent unit speaker turns on for soft babbling and louder sounds from your baby. It remains quiet

The parent unit speaker turns on for loud babbling Medium and louder sounds from your baby. It remains When the screen is turned off, you can still hear quiet when your baby

3. Press ▼ or ▲ to choose the desired time

3. Press ▼ or ▲ to choose the desired level of brightness, then press **SELECT** to confirm your selection.

	Description
	2 000р
ı	Highest VOX sensitivity
sitivity	level
,	The parent unit speaker
	is constantly on, and
- 1	you will hear all sounds
- 1	(including background

when your baby sleeps

Medium VOX sensitivity

makes soft sounds.

Low VOX sensitivity

The parent unit speake

turns on for crying and

baby. It remains quiet

soft sounds.

louder sounds from your

when your baby makes

Lowest VOX sensitivity

The parent unit speake

turns on for loud crying

or screeching sounds

quiet when your baby

makes soft sounds.

from vour baby. It remain:

screen to turn on automatically. When no sound is detected within 50 seconds, the screen will be off again. Press MENU when the parent unit is idle.

improve the sound detection.

Turn on or off the sound

When sound activation is on, as long as no

parent unit screen will turn off automatically to

When your baby unit detects a sound, which

2. Press ◀ or ▶ to choose ⑧, then press ▲

exceeds the selected sensitivity level, the


sound activation triggers the parent unit

sound is detected within 50 seconds, the

3. Press ▼ or ▲ to choose on or off, then press SELECT to confirm your selection.

Adjust speaker volume

- your parent unit.
- 2. Press ◀ or ▶ to choose , , then press ▲.





Monitoring mode

the lullaby on the baby unit.

Every time the parent unit is turned on, it displays a baby unit in SINGLE-CAM mode.





PATROL mode: 1. Press **MENU** when the parent unit is idle. 2. Press ◀ or ▶ to choose • then press ▲.

selection In PATROL mode, the camera view transits to a different baby unit every 10

3. Press ▼ or ▲ to switch on or off PATROL


mode, then press **SELECT** to confirm your







Operating range









You can zoom in while viewing images from

- the baby unit.
- Press
 to zoom in. Press and hold ▲ or ▼ to move the

zoomed image upward or downward.

- Press and hold ◀ or ▶ to move the zoomed
- image leftward or rightward.

You can use the TALK function of the parent unit to comfort your baby.

- 1. Press and hold TALK on the parent unit. The TALK light turns on.
- 2. Speak towards the microphone on the parent unit. Your voice is broadcast to the baby unit.
- 3. Release the TALK key to stop the broadcast. The **TALK** light goes off.

Lullaby

is ended.

The baby monitor has five lullabies and four soothing sounds for you to comfort your baby. You can play the lullabies or soothing sounds on the baby unit using the parent unit.

- 1. Press **MENU** when the parent unit is idle. 2. Press ◀ or ▶ to choose , , then press ▲.
- 3. Press ▲ to choose 🍇, then press ◀
- 4. Press ▼ or ▲ to choose a lullaby, or choose to stop playing. 5. Press **SELECT** to confirm your selection.
- **Ø**NOTE
- The lullaby stops when you started using TALK function of the parent unit to comfort your baby. It will resume in a few seconds after the broadcast

Monitor the temperature

Your baby unit monitors the temperature of your baby's room with its built-in temperature sensor. If the detected temperature is out of the preset temperature range, the parent unit will display an alert message.

Set temperature range

You can set the desired room temperature alert range. The minimum temperature can be set between 50 °F (10 °C) and 76 °F (24 °C). The maximum temperature can be set between 77 °F (25 °C) and 102 °F (39 °C).

- 1. Press **MENU** when the parent unit is idle. 2. Press ◀ or ▶ to choose ຝ, then press ▲.
- Press ▼ or ▲ to choose
 then press ◄.
- 4. Press ▼ or ▲ to choose MIN or MRX, then press **SELECT**.
- 5. Press ▼ or ▲ to choose the desired minimum or maximum temperature, then press **SELECT** to confirm your selection.

Temperature alert tone You can turn on the temperature alert tone so

that the parent unit will emit an alert tone if the detected temperature is out of range. 1. Press **MENU** when the parent unit is idle.

- Press ◀ or ▶ to choose ♣, then press ▲.
- 3. Press ▼ or ▲ to choose ♣ , then press SELECT.
- 4. Press ▼ or ▲ to choose N or F, then press SELECT to confirm your selection.

Temperature format You can choose to display the temperature in

Fahrenheit (°F) or Celsius (°C).

- 1. Press **MENU** when the parent unit is idle. 2. Press ◀ or ▶ to choose ♠, then press ▲.
- 3. Press ▼ or ▲ to choose 🔓, then press SELECT.
- 4. Press ▼ or ▲ to choose F or C, then press **SELECT** to confirm your selection.

Night vision

The baby unit has infrared LEDs that allow you to see your baby clearly at night or in a dark room. When the baby unit being viewed detects low light levels, the infrared LEDs are switched on automatically. The images from the baby unit are in black and white, and 🐿 appears on screen **Ø**NOTES

- It is normal if you see a short white glare on your parent unit screen as the baby unit is adapting to • When the infrared LEDs are on, the images are in
- black and white. This is normal.

 Depending on the surroundings and other interfering factors, like lightings, objects, colors and backgrounds, the display resolution may vary Adjust the baby unit's angle or place the baby unit at a higher level to prevent glare and blurry display.

Your baby monitor comes ready for tabletop

use. You can also choose to mount your baby monitor on the wall. See Mount the baby unit (optional) in the Quick Start Guide for the wall mounting instructions.

General product care

- Avoid putting it near heating appliances and devices that generate electrical noise (for example, motors or fluorescent lamps).
- Avoid dropping the product or treating it roughly. Clean with a soft cloth.
- DO NOT immerse the parent unit and the baby
- Make sure the baby unit and parent unit are dry before you connect them to the mains again

Why does the The parent unit and baby units may Frequently asked questior baby monitor

Below are the questions most frequently asked about the baby monitor. If you cannot find the answer to your question, visit our website at www.vtechphones.com. or contact 1 (800) 595-9511 for customer service.

Why does the baby monitor not respond normally?	Try the following (in the order listed) for common cure: 1. Disconnect the power to the baby units and the parent unit. 2. Remove the batteries in the parent unit. Then, install the batteries again. 3. Wait a few seconds before connecting power back to the baby units and the parent unit. 4. Turn on the baby units and the parent unit. 5. Wait for the parent unit to synchronize with the baby units. Allow up to one minute for this to take place.
Why don't the power-on light of the baby unit and parent unit go on when I switch on the	Perhaps the parent unit is not connected to the power. Insert the appliance plug into the parent unit and put the adapter in a wall socket Then, press and hold O to switch on the parent unit and to establish connection with the baby unit.

Perhaps the baby unit is not

connected to the power, Insert

the appliance plug into the baby

unit and put the adapter in a wal

socket. Then, slide the **ON/OFF**

unit and to establish connection

Make sure the battery is installed

ou may have used the battery for

a long time. Replace a new batter

The screen is in black and white

during night-time or in a dark roon

when the night vision feature is

During night-time or in a dark

room, the surroundings and othe

your parent unit screen. Adjust the

paby unit's angle or place the baby

interfering factors, like lightings,

objects, colors and background

may affect the image quality on

unit at a higher level to prevent

glare and blurry display.

activated. This is normal.

Make sure the power is not

controlled by a wall switch.

with the parent unit.

switch to ON to switch on the baby

The baby units may be out of the parent range. Move the parent unit close unit beep' to the baby units (but not less than If the parent unit is powered by the enough charge for the parent unit to perform normally. Charge the batter in the parent unit for up to 11 hours. The temperature of your baby's room may be too high or too low Why does The baby unit also picks up other the parent sounds than those of your baby. unit react Adjust the sensitivity level to a too quickly lower level or lower the parent up speaker volume. to other sounds? Why don't The parent unit speaker volume hear a

be too close to each other

stops; ÓR

parent unit.

Move the parent unit away from

Turn down the volume of your

the baby units until the noise

oroduce a

high-pitched

lost every

now and

are there

interruptions?

may be too low or off. Press VOL+ sound/Why to increase the volume. can't I hear You may have set a low sound my baby cry? sensitivity level. See Adjust the sound sensitivity of the baby 8. The power adapters are intended to be correctly unit to set to a higher level. Why can't I The baby units may be out of

ange. Move the parent unit close

monitor as far away from these

electronic devices as possible.

onnection? o the baby units (but not less tha For pluggable equipment, the socket-outlet shall Why is the be installed near the equipment and shall be easily accessible. Other electronic products may 10. Unplug this product from the wall outlet before cause interference with your bab cleaning. Do not use liquid or aerosol cleaners. onitor. Try installing your baby

12. Do not cut off the power adapters to replace them with other plugs, as this causes a hazardous situation.

11. Unplug the power cords before replacing

Use a damp cloth for cleaning.

- 13. Do not allow anything to rest on the power cords Do not install this product where the cords may be walked on or crimped. 14. This product should be operated only from the
- type of power source indicated on the marking label. If you are not sure of the type of powe supply in your home, consult your dealer or local power company. 15. Do not overload wall outlets or use an extension
- 16. Do not place this product on an unstable table. shelf, stand or other unstable surfaces.
- 17 This product should not be placed in any area where proper ventilation is not provided. Slots and openings in the back or bottom of this

portant safety instruction

injury, including the following:

a wet basement or shower

This product is intended as an aid. It is not

a substitute for responsible and proper adult

supervision and should not be used as such

4. This product is not intended for use as a medical

5. Do not use this product near water. For example,

. CAUTION: Use only the batteries indicated in

this manual. There may be a risk of explosion

if a wrong type of battery is used for the parent

or replacement battery pack (BT207695) for

unit. Use only the supplied rechargeable battery

he parent unit. Do not dispose of batteries in a

fire. They may explode. Dispose of used batter

Use only the adapters included with this product.

Baby unit power adapter: Output: 6V DC 500mA

Parent unit power adapter: Output: 6V DC 500mA

oriented in a vertical or floor mount position. The

if it is plugged into a ceiling, under-the-table or

prongs are not designed to hold the plug in place

Incorrect adapter polarity or voltage can

seriously damage the product.

according to the information in The BBBC® seal

kitchen sink, laundry tub or swimming pool, or in

do not use it next to a bath tub, wash bowl.

Adult setup is required

the product.

When using your equipment, basic safety precautions should always be followed to reduce the risk of fire, electric shock and Follow all warnings and instructions marked on

- through the slots because they may touch dangerous voltage points or create a short circuit. Never spill liquid of any kind on the
- 19. To reduce the risk of electric shock, do not

18. Never push objects of any kind into this product

product are provided for ventilation. To protect

em from overheating, these openings must

not be blocked by placing the product on a soft

surface such as a bed, sofa or rug. This product

should never be placed near or over a radiator or

- disassemble this product, but take it to an authorized service facility. Opening or remove parts of the product other than specified access doors may expose you to dangerous voltages or other risks. Incorrect reassemblin can cause electric shock when the product is subsequently used. 20. You should test the sound reception every
- time you turn on the units or move one of the components 21. Periodically examine all components for
- damage.
- 22. Be aware of possible loss of privacy while using public airwayes. Conversations may be picked up by other nursery monitors, cordless phones, scanners, etc.
- 23. Children should be supervised to ensure that they do not play with the product.
- 24. The product is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for

SAVE THESE INSTRUCTIONS

- 1. Use and store the product at a temperature etween 32°F and 104°F Do not expose the product to extreme cold, heat
- or direct sunlight. Do not put the product close to a heating source
- 3. Batteries should not be exposed to excessive heat such as bright sunshine or fire.
- Hazard—Children have STRANGLED in cords. Keep this cord out of the reach of children (more than 3 ft (0.9 m) away). Do not remove this 5. Never place the baby unit(s) inside the baby's crib
- or playpen. Never cover the baby unit(s) or parent unit with anything such as a towel or a blanket. Other electronic products may cause
- interference with your baby monitor. Try installing your baby monitor as far away from these electronic devices as possible wireless routers, radios, cellular telephones, intercoms, room monitors, televisions personal computers, kitchen appliances and cordless telephones.

Precautions for users of implanted cardiac pacemakers Cardiac pacemakers (applies only to digital cordless

Wireless Technology Research, LLC (WTR), an independent research entity, led a multidisciplinary evaluation of the interference between portable wireless devices and implanted cardiac pacemakers. Supported by the U.S. Food and Drug Administration, WTR recommends to physicians that: Pacemaker patients

Should keep wireless devices at least six inches from the pacemaker

- · Should NOT place wireless devices directly over
- the pacemaker, such as in a breast pocket, when it is turned ON. WTR's evaluation did not identify any risk to

bystanders with pacemakers from other persons using wireless devices. Electromagnetic fields (EMF)

This VTech product complies with all standards

regarding electromagnetic fields (FMF). If handled properly and according to the instructions in this user's manual, the product is safe to be used based on scientific evidence available today

The RBRC® seal

1 (800) 8 BATTERY® for information on Ni-MH

and conserving natural resources.

are registered trademarks of the

Rechargeable Battery Recycling

RBRC® and 1 (800) 8 BATTERY®

battery recycling and disposal bans/restrictions in

your area. VTech's involvement in this program is

part of its commitment to protecting our environment

that VTech Communications. Inc. is voluntarily participating in an industry program to collect and recycle these batteries at the end of their useful lives, when taken out of service within the United The RBRC® program provides a convenient

alternative to placing used Ni-MH batteries into the trash or municipal waste, which may be illegal in parent unit shall be held at least 1 in (2.5 cm) from vour face. VTech's participation in RBRC® makes it easy for

This Class B digital apparatus complies with you to drop off the spent battery at local retailers participating in the RBRC® program or at authorized CAN ICES-3 (B)/NMB-3(B) VTech product service centers. Please call

This device complies with Industry Canada licence-

Operation is subject to the following two conditions 1) this device may not cause harmful interference, nd (2) this device must accept any interference including interference that may cause undesired operation

technical specifications

RF radiation exposure statement

This equipment has been tested and found to nission (FCC) rules. These requirements are

- and receiver. Connect the equipment into an outlet on a
- Consult the dealer or an experienced radio/TV technician for help.

esponsible for compliance could void the user's authority to operate the equipment

For C-UL compliance onl

Mesures de sécurité importantes Lorsque vous utilisez votre appareil, vous devriez toujours suivre certaines mesures de précaution

ceux qui suivent Observez toutes les instructions et mises en garde inscrites sur l'appareil.

de base afin de réduire les risques d'incendie,

d'électrocution et de blessures corporelles, dont

- L'installation par un adulte est requise Ce produit a été concu pour être un dispositif d'appoint seulement. Il n'est pas le remplacemen d'une supervision responsable et adéquate par un adulte et ne devrait pas être utilisé comme
- . Ce produit n'est pas conçu pour être utilisé en tant que moniteur médical.
- N'utilisez pas cet appareil près de l'eau ni de toute autre source d'humidité, par exemple, près d'une baignoire, cuve à lessive, évier de cuisine, dans un sous-sol humide ni près d'une piscine, dans un soussol humide ou une douche.
- MISE EN GARDE: Il peut y avoir un risque d'explosion si vous utilisez le mauvais type de piles pour l'unité du parent. N'utilisez que le bloc-piles rechargeable inclus ou le bloc-piles de rechange (BT207695). N'incinérez pas les piles. Celles-ci risqueraient d'exploser. Jetez les piles usées selon les renseignements suivant le sceau du RBRC®
- sez que les adaptateurs inclus avec (produit. L'utilisation d'un adaptateur dont la polarité ou la tension serait inadéquate risque d'endommager sérieusement le produit et mettre votre sécurité en péril. Adaptateur de l'unité du bébé Sortie: 6V CC 500mA Adaptateur de l'unité du parent
- Sortie: 6V CC 500mA Lorsqu'ils sont branchés dans une prise de courant, les adaptateurs secteur ont été conçus pour être orientés correctement, soit à la verticale ou au plancher. Les broches n'ont pas été conçues pour supporter le poids du bloc d'alimentation et le maintenir en place si celuici est branché dans une prise au plafond, sous une able ou dans un meuble
- PRISE DE COURANT, la prise de courant doit être installée près du produit, afin d'assurer une accessibilité sécuritaire à la prise de courant. 10. Débranchez ce produit de la prise de courant avant de procéder au nettoyage. N'utilisez pas de nettovants en aérosols. Utilisez un chiffon humide

Pour les PRODUITS À BRANCHER À UNE

11. Débranchez les cordons d'alimentation avant de remplacer le bloc-piles. 12. Ne coupez pas les cordons d'alimentation pour

pour le nettoyer.

remplacer les fiches, car ceci peut présenter un danger potentiel.

- 13. Ne laissez aucun objet reposer ni appuyer sur le cordon d'alimentation. N'installez pas cet appareil dans un endroit où l'on risque d'écraser
- e cordon d'alimentation ou de le piétiner. 14. Ne faites fonctionner cet appareil qu'avec le type d'alimentation indiqué sur l'étiquette. Si vous ne connaissez pas le type d'alimentation que vous possédez à votre domicile, consultez votre marchand ou votre compagnie locale
- 15. Ne surchargez pas les prises de courant murales ni les rallonges électriques. 16. Ne placez pas cet appareil sur un chariot,

d'électricité.

meuble, trépied, support de montage ni table chancelants. 17. Les trous et ouvertures du boîtier, situés à l'arrière de l'appareil ou sous celui-ci, servent à aérer l'appareil. Pour l'empêcher de surchauffer, ne bloquez sous aucun prétexte ces ouvertures et n'empêchez pas l'aération adéquate de l'appareil en le placant sur un lit, divan, tapis ou toute autre surface similaire. De même, ne le

positionnez pas à proximité ni au-dessus d'une

source de chaleur ou d'un calorifère. De plus,

ne placez pas l'appareil dans un endroit avant

de vous assurer qu'il y ait une bonne circulation

- 18. N'enfoncez jamais d'objets à travers les ouvertures de cet appareil, car ils pourraient entrer en contact avec des points de tension dangereux ou causer des courts-circuits qui peuvent dégénérer en incendies ou en risques d'électrocution. Ne renversez jamais de liquide dans ce produit.
- 19. Afin de réduire les risques d'électrocution, ne démontez pas cet appareil, mais apportez-le dans un centre de service autorisé. L'ouverture du boîtier ou le retrait de toutes pièces que contient cet appareil, à l'exception de l'accès autorisé à certaines portes ou ouvertures, risque de vous exposer à des points de tension dangereux ou d'autres dangers. Un remontage incorrect peut par la suite présenter des risques d'électrocution
- vous mettez l'appareil en fonction 21. Examinez les composantes afin de vérifier si
- celles-ci ne sont pas endommagées. 22 Sovez avisé de la perte de la confidentialité

20. Vous devriez tester la réception chaque fois que

lorsque vous utilisez les ondes publiques. Les conversations peuvent être entendues par d'autres moniteurs de bébé, des téléphones sans fil, des scanneurs, etc. 23. Les enfants devraient être supervisés afin de

vous assurer qu'ils ne jouent pas avec l'appareil

- 24. Le produit n'est pas concu pour être utilisé par des personnes (incluant des enfants) aux capacités physiques, sensorielles ou mentales
- réduites ou qui manquent d'expérience et de connaissances, à moins qu'on leur ait donné suffisamment de supervision ou d'instructions relativement à l'utilisation de l'appareil par une personne responsable de leur sécurité. **CONSERVEZ CES INSTRUCTIONS**

Why does

my parent

unit charge

connected to

AC power?

Why do I

get glare or

on my screen

when viewing

Mount the baby unit (optional)

- To keep this product working well and looking good,
- DO NOT expose it to direct sunlight or moisture.
- unit in water and do not clean them under the tap. DO NOT use cleaning spray or liquid cleaners.

Storage

Mises en garde

When you are not going to use the baby monitor for some time, remove the rechargeable battery from the parent unit. Store the parent unit, the baby unit and the adapters in a cool and dry place.

Utilisez et entreposez le produit à une

température entre 0° C (32°F) et 40°C (104° F). 2. N'exposez pas cet appareil à des froids ou des chaleurs extrêmes, ainsi qu'à la lumière directe du soleil. Ne l'installez pas près d'une source de

ou au feu. 4. Assurez-vous que le moniteur et le cordon de l'adaptateur sont toujours hors de portée des enfants, àau moins 1

risque de strangulation.

berceau ou du parc de bébé. Ne jamais couvrir tel une serviette ou une couverture D'autres équipements électroniques peuvent produire des interférences sur votre moniteur vidéo et audio. Tentez d'installer votre électroniques tels que des routeurs sans fil. radios, téléphones cellulaires, interphones,

dispositifs numériques sans fil) L'organisme 'Wireless Technology Research, LLC (WTR)', une firme de recherche indépendante. a mené une évaluation pluridisciplinaire des interférences entre les téléphones sans fil portatifs et les stimulateurs cardiaques implantés dans l'organisme. Appuyée par l'Administration des aliments et drogues (FDA) des États-Unis, la firme WTR recommande aux médecins:

- Ils ne doivent PAS placer le téléphone sans fil directement sur le stimulateur cardiaque, tel que dans une poche de chemise, lorsque celui-ci est L'étude effectuée par l'organisme WRS n'a pas
- Champs électromagnétiques (EMF) Ce produit de VTech est conforme à toutes les normes se rapportant aux champs électromagnétiques (EMF) standard. Si vous le manipulez correctement en suivant les instructions de ce guide, son utilisation sera sécuritaire pendant de nombreuses années, selon les meilleures évidences scientifiques dont nous disposons

_imited warranty

- What does this limited warranty cover? The manufacturer of this VTech Product warrants to the holder of a valid proof of purchase ("Consumer" or "vou") that the Product and all accessories 3. Le bloc-piles ne doit pas être exposé à la
- provided in the sales package ("Product") are chaleur excessive telle que la lumière du soleil free from defects in material and workmanship pursuant to the following terms and conditions, when installed and used normally and in accordance with the Product operating instructions. This limited warranty extends only to the Consumer for Products purchased and used in the United States of America mètre (3 pieds) de l'enfant ou and Canada. du berceau, pour éviter tout
- le moniteur ou l'unité (s) portative avec un article moniteur vidéo ou audio à l'écart des appareils

moniteurs, téléphones, ordinateurs personnels,

Ne jamais placer le moniteur à l'intérieur du

Stimulateurs cardiaques implantés dans

électroménagers et téléphones sans fil.

Les simulateurs cardiaques (ne s'applique qu'aux

Avis aux détenteurs de stimulateurs cardiaques Vous devriez maintenir les dispositifs sans fil à au moins six pouces du simulateur cardiaque.

- identifié de risque pour les détenteurs de simulateurs liquid intrusion; or cardiaques causés par les gens qui utilisent dispositifs sans fil à proximité de ceux-ci.
 - is caused by signal conditions, network reliability, or cable or antenna systems; or 4. Product to the extent that the problem is caused by use with non-VTech accessories: or

(see item 2 below); or 8. Charges for installation or set up, adjustment of

What will VTech do if the Product is not free from defects in materials and workmanship during the limited warranty period ("Materially Defective

Product")? During the limited warranty period, VTech's authorized service representative will repair or replace at VTech's option, without charge a Materially Defective Product. If we repai the Product, we may use new or refurbished replacement parts. If we choose to replace the Product, we may replace it with a new or refurbished Product of the same or similar design. We will etain defective parts, modules, or equipmen Repair or replacement of the Product, at VTech's option, is your exclusive remedy. VTech will return the repaired or replacement Products to you in working condition. You should expect the repair or

VTech repairs or replaces a Materially Defective Product under the terms of this limited warranty, this limited warranty also applies to the repaired or replacement Product for a period of either (a) 90 days from the date the repaired or replacement Product is shipped to you or (b) the time remaining

on the original one-year warranty; whichever is

What is not covered by this limited warranty?

- This limited warranty does not cover: 1. Product that has been subjected to misuse. accident, shipping or other physical damage, mproper installation, abnormal operation or handling, neglect, inundation, fire, water or other 2. Product that has been damaged due to repair,
- 5. Product whose warranty/quality stickers, product

alteration or modification by anyone other than an

authorized service representative of VTech: or

3 Product to the extent that the problem experienced

serial number plates or electronic serial numbers have been removed, altered or rendered illegible:

or Canada, or used for commercial or institutional purposes (including but not limited to Products used for rental purposes); or 7. Product returned without a valid proof of purchase

systems outside the unit. How do you get warranty service?

call 1 (800) 595-9511. In Canada, go to www.vtechcanada.com or call 1 (800) 267-7377 NOTE: Before calling for service, please review the user's manual - a check of the Product's controls and features may save you a service call. Except as provided by applicable law, you assume the risk of loss or damage during transit and ransportation and are responsible for delivery or handling charges incurred in the transport of the Product(s) to the service location. VTech will return repaired or replaced Product under this limited warranty. Transportation, delivery or handling charges are prepaid. VTech assumes no risk for damage or loss of the Product in transit. If the Product failure is not covered by this limited warranty, or proof of purchase does not meet the terms of this limited warranty, VTech will notify you and will request that you authorize the cost of repair prior to any further return shipping costs for the repair of Products that

To obtain warranty service in the USA, please visit

our website at www.vtechphones.com or

What must you return with the Product to get warranty service?

2. Include a "valid proof of purchase" (sales receipt) identifying the Product purchased (Product model) and the date of purchase or receipt; and

Other limitations

This warranty is the complete and exclusive

State/Provincial Law Rights: This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state or province to province. 6. Product purchased, used, serviced, or shipped for repair from outside the United States of America

Limitations: Implied warranties, including those of fitness for a particular purpose and merchantability (an unwritten warranty that the Product is fit for ordinary use) are limited to one year from the date of purchase Some states/provinces do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you. In no event shal VTech be liable for any indirect, special, incidental customer controls, and installation or repair of consequential, or similar damages (including, but not limited to lost profits or revenue, inability to use the Product or other associated equipment, the cos

limitation or exclusion may not apply to you. Please retain your original sales receipt as proof of purchase.

of substitute equipment, and claims by third parties)

resulting from the use of this Product. Some states

provinces do not allow the exclusion or limitation of

incidental or consequential damages, so the above

chnical specifications

Frequency control	Crystal controlled PLL synthesizer
Transmit frequency	Baby unit: 2405 - 2475 MHz Parent unit: 2405 - 2475 MHz
Channels	32
LCD	2.8" Color LCD (WQVGA 320x240 pixel)
Nominal effective range	Maximum power allowed by FCC and IC. Actual operating range may vary according to environmental conditions at the time of use.
Power requirements	Parent unit: 3.6V Ni-MH battery Baby unit power adapter: Output:

6V DC @ 500mA

6V DC @ 500mA

Parent unit power adapter: Output:

FCC Part 15

FCC and IC regulations

Corporation.

States and Canada.

your area.

comply with the requirements for a Class B digital device under Part 15 of the Federal Communications intended to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful nterference to radio communications. However there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna. • Increase the separation between the equipment

circuit different from that to which the receiver is

WARNING: Changes or modifications to this equipment not expressly approved by the party

> This device complies with Part 15 of the FCC rules Operation is subject to the following two conditions

The RBRC® seal on the Ni-MH battery indicates

undesired operation. To ensure safety of users, the FCC has established criteria for the amount of radio frequency energy that can be safely absorbed by a user or bystander according to the intended usage of the product. This product has been tested and found to comply with he FCC criteria. The baby unit shall be installed and used such that parts of all persons' body are maintained at a distance of approximately 8 in (20) cm) or more. The transmitter and antenna of the

(1) this device may not cause harmful interference,

nd (2) this device must accept any interference

received, including interference that may cause

Industry Canada

exempt RSS standard(s)

The term "IC:" before the certification/registration number only signifies that the Industry Canada technical specifications were met. This product meets the applicable Industry Canada

The baby unit complies with FCC RF radiation

exposure limits set forth for an uncontrolled environment. The baby unit should be installed and operated with a minimum distance of 8 in (20 cm) between the baby unit and all persons' body. Use o accessories may not ensure compliance with FCC RF exposure guidelines. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. Thiś equipment complies also with Industry Canada RSS-102 with respect to Canada's Health Code 6 for Exposure of

California Energy Commission ttery charging testing mode This baby monitor meets the California Energy

mmission (CEC) regulations for energy consumption. Your baby monitor is set up to comply with the energy-conserving standards right out of the Follow the instructions to install and charge the battery. The CEC battery charging testing mode is

activated while charging. Even if the parent unit is paired to baby units. the CEC battery charging testing mode is activated while it is powered off and charging.



eplacement to take approximately 30 days How long is the limited warranty period? The limited warranty period for the Product extends epair activity. You must pay for the cost of repair and for ONE (1) YEAR from the date of purchase. If are not covered by this limited warranty.

1. Return the entire original package and contents including the Product to the VTech service location along with a description of the malfunction or difficulty: and

- 3. Provide your name, complete and correct mailing address, and telephone number.
- agreement between vou and VTech. It supersedes all other written or oral communications related to this Product. VTech provides no other warranties for this Product. The warranty exclusively describes all of VTech's responsibilities regarding the Product. There are no other express warranties. No one is authorized o make modifications to this limited warranty and you should not rely on any such modification.

Specifications are subject to change without notice

© 2018 VTech Communications, Inc. All rights reserved. 01/18. VM3252-X_CIB_V4 Document order number: 91-010825-030-100