



WALKER'S
OWNER'S MANUAL

GWP-RDOM

HEARING PROTECTOR WITH DIGITAL AM/FM RADIO

The GWP-RDOM is an ideal Hearing Protector built with a digital AM/FM stereo radio. The noise-cancellation radio sound is fascinating in noisy environments. It is specifically designed to protect your hearing when working under noisy conditions and creates a suitable working atmosphere by listening to the radio.

IDENTIFYING MUFF COMPONENTS:

1. Antenna with superb reception sensitivity
2. Wide headband with soft padding
3. Stainless steel wire with elasticity
4. Cable connecting speaker & power
5. Battery cover for easy battery replacement
6. Height adjustment guide arm
7. Foam pad ear cushion for comfort
8. Digital display screen with low battery indicator
9. Set button
10. AM/FM button
11. Volume control knob
12. Radio on/off power switch
13. Ear cups
14. Function Knob (TURN +)
15. Input jack for MP3 or CD player



INSTRUCTIONS FOR USE:

1. TIME SETTING

After inserting the battery, system automatically turns into time display. You will see a clock icon ⌚ icon the upper left hand corner of the LCD screen. "DO NOT PUSH THE ON/OFF BUTTON AT THIS TIME". The default time is "0:00" in 24 hr format. Turn Function Knob (No. 14) clockwise to change between 12 and 24 hours format.

To adjust the time, press [SET] button once. Hour will be flashing. Turn Function Knob to set the hour. When complete

press [SET] button again to adjust minute. When complete press [SET] button to return to time display.

During the setting process if no action was done within 15 seconds, the system will return back to time display.

2. RADIO ON/OFF

Press [ON/OFF] button to turn the radio on and off.

3. OPERATING FREQUENCY SELECTION

Press [AM/FM] button to change between AM and FM frequency.

4. VOLUME ADJUSTMENT

Press the volume control button [VOL]. Volume level will be displayed on the upper right corner of the LCD screen. [8]

Use the Function Knob (No. 14) to adjust your volume. ^{Vol} Make sure you adjust the volume slowly to avoid any sudden increase in loud sound that could potentially be harmful to your ears.

Press the [VOL] button to exit volume adjustment.

5. OPERATING FREQUENCY ADJUSTMENT

When radio is operating in FM mode, turn Function Knob (no. 14) to adjust the radio frequency range from 87.5MHz ~ 108MHz.

When radio is operating in AM, turn Function Knob (no. 14) to adjust the radio frequency range from 522KHz ~ 1710 KHz.

To scan and search channel automatically, push in the Function Knob.

6. CHANNEL MEMORY FUNCTION

There are 8 preset channels memory function available.

1). When radio is on, turn the Function Knob (No. 14) to select your channel. Press and hold [SET] button for 2 seconds to activate memory mode, then turn the Function Knob (No. 14) again to select memory location where you would like to store the channel. Confirm your selection by pressing [SET].

2). To choose preset channel stations that you've saved, press and hold [SET] for less than 2 seconds, turn the Knob to select your desired preset channel station.

Installing and Replacing Batteries:

Open the battery cover. Remove the battery from compartment and replace with two new Size AA Alkaline batteries. Note the direction of the positive (+) and negative (-) poles.

Do not mix old and new batteries

Do not mix alkaline, standard, or rechargeable batteries.

Caring For Your Radio Muff:

Remember that your Radio Muff are a quality instrument and should be treated in the same careful manner as any other precision-engineered device.

1. Never allow any liquid to enter the Radio Muff as this may damage the components within the device.
2. Do not store your Radio Muff in any location that would expose it to excessive heat (for example, in direct sunlight, near car dashboards, heaters or radiators).
3. Be careful not to drop your Radio Muff as this may damage its components.
4. Never insert any foreign objects into your Radio Muff. This could result in serious damage to the instrument.
5. Never permit solvents to come into contact with your Radio Muff as this can damage the units.
6. Clean your Radio Muff by wiping with a damp cloth moistened with a mild cleanser.

LIMITED WARRANTY

Walker's warrants this product to the original purchaser to be free from defects in materials and workmanship, under normal use and conditions for a period of two years parts/90 days labor from the date of the original purchase.

Under this warranty, this unit will be replaced or repaired at our option, without charge for parts or labor, excluding batteries, for a period of 90 days after the purchase. After 90 days, the cost of labor with Shipping/Handling and Insurance of \$29.95 (Radio MUFF only) is the customer's responsibility. Copy of original receipt may be required for any warranty service.

This warranty is void if any of the following occur:

1. The warranty card was not sent in at the time of purchase
2. The unit is not owned by the original purchaser at the time of the warranty claim
3. The unit has been tampered with, opened or punctured
4. The unit has been immersed in water or other liquids, allowed to be filled with dirt or dust, or otherwise physically abused
5. The 90 days limited warranty has expired

This shall be the exclusive written warranty of the original purchaser and neither this warranty or any other warranty, expressed or implied, shall extend beyond the 90 days period listed above. In no event shall Walker's Game Ear, Inc. be liable for consequential damages, consequential property damage, or consequential personal injury. (Some states do not allow limitations on implied warranties or exclusions of consequential damages, so that these restrictions may not apply to you). This warranty gives you specific legal rights, and you may have other rights, which vary from state to state.

Rev. 1/5/15

Return bottom portion to: Walker's, Inc. • PO Box 535189 • Grand Prairie, TX 75053-5189
Or you can register your product online at: www.WalkersGameEar.com

Warranty Registration

Model: _____ Date of Purchase: _____

Purchased From _____

City: _____ State: _____ Zip: _____

Primary Use: _____

Your Name: _____

Address: _____

City: _____ State: _____ Zip: _____

email address: _____