

DESK WIRELESS ALARM CLOCK CHARGER

USER MANUAL



FEATURES:

- Calendar years 2000–2049
- Display mode: time display & temperature
- 12/24 hour format selectable (initial mode: 24 hours, January 2015; time 12:00)
- Every time can set up three groups of alarms, each ringing for 1 minute, you can turn on/off the weekend alarm by the button “up”
- Each snooze function - 5 minutes, Snooze state press any key to exit and snooze alarm
- DC 5/500MA(3*AAA) power supply; built-In battery slot
- Time display program running inside but invisible outside



DESCRIPTION:

This is a Desk Wireless Alarm Clock Charger that supports fast charging and is compatible with various Qi-Certified Smart Phones such as iPhone, Samsung, Google Pixel, and others. Simply place your phone on top of the clock before going to bed, and when you wake up in the morning, your phone will be fully charged.

Additionally, this clock features a Sounds Control Mode where you can turn off the screen after 10 seconds by selecting "oN:Sd" and waking the screen back up by "clapping" your hands. If you don't prefer this mode, you can opt for the "-:Sd" option to disable it. When the voice control is turned off, the time will always be displayed.

Moreover, this digital alarm clock has three adjustable brightness levels to cater to your different needs during the day and night. You can also turn off the LED display, which is an ideal design for light-sensitive sleepers.

You can set three different alarm times with this Desk Wireless Charger, and it displays both 12/24H clock formats. It makes for a perfect gift with its wooden decoration, fashionable design, and multi-functional features, ideal for your parents. You can place it on your bedside table, nightstand, or desk, or even take it with you while travelling.

OPERATION:

- Press the button "set" for 3 seconds to enter setting mode, you can set year, month, date, 12H/24H, hour, minute and alarm in order
- Use buttons "UP" and "DOWN" to adjust the year, month, date and time.
- Button "set" alarm off (--A1), "UP" and "DOWN" to on/off, displaying: "ON AL" / "--AL", then "UP" and "DOWN" for an hour setting, then "UP" and "DOWN" for minute setting
- Follow these steps to set the (A2) and (A3)
- Use the "UP" and "DOWN" buttons to choose °C/°F
- Use the button "SET" to exit.
- Button "SET": adjust and exchange display modes
- Button "UP": weekend alarm setting
- Turn on/off, displaying: "ON EA" / "--EA"
- Button "DOWN": turn DOWN or sound control on/off



BRIGHTNESS ADJUSTMENT

- In the normal travel time mode, long press the down key for 3 seconds to enter the brightness adjustment mode.
- Display: [A: Lu] is the automatic brightness mode
- [1: Lu] Brightness level 1, darkest
- [2: Lu] Brightness level 2
- [3: Lu] Brightness level 3
- [4: Lu] Brightness level 4
- [5: Lu] Brightness level 5, brightest
- Press down to switch between 6 brightness modes

